

# **SCE Interface Reference**

**(CRAY T90™ Series)**

**HDM-182-C**

Cray Research/Silicon Graphics Proprietary



# Record of Revision

---

REVISION	DESCRIPTION
----------	-------------

---

	August 1995. Original printing.
A	March 1996. This revision corresponds to the MT-T2.2.0 offline diagnostic release.
B	June 1996. This revision corresponds to the MT-T2.2.1 offline diagnostic release.
C	August 1997. This revision corresponds to the MT-T2.3.0 offline diagnostic release.

---

Any shipment to a country outside of the United States requires a letter of assurance from Cray Research, Inc.

---

This document is the property of Cray Research, Inc. The use of this document is subject to specific license rights extended by Cray Research, Inc. to the owner or lessee of a Cray Research, Inc. computer system or other licensed party according to the terms and conditions of the license and for no other purpose.

---

Cray Research, Inc. Unpublished Proprietary Information — All Rights Reserved.

---

Autotasking, CF77, CRAY, CRAY-1, Cray Ada, CraySoft, CRAY Y-MP, CRInform, CRI/TurboKiva, HSX, LibSci, MPP Apprentice, SSD, SUPERCLUSTER, UNICOS, and X-MP EA are federally registered trademarks and Because no workstation is an island, CCI, CCMT, CF90, CFT, CFT2, CFT77, ConCurrent Maintenance Tools, COS, CRAY-2, Cray Animation Theater, CRAY APP, CRAY C90, CRAY C90D, Cray C++ Compiling System, CrayDoc, CRAY EL, CRAY J90, CRAY J90se, CrayLink, Cray NQS, Cray/REELibrarian, CRAY S-MP, CRAY SSD-T90, CRAY T3D, CRAY T3E, CRAY T3E-900, CRAY T90, CrayTutor, CRAY X-MP, CRAY XMS, CSIM, CVT, Delivering the power . . ., DGauss, Docview, EMDS, GigaRing, HEXAR, IOS, ND Series Network Disk Array, Network Queuing Environment, Network Queuing Tools, OLNEL, RQS, SEGLDR, SMARTE, SUPERLINK, System Maintenance and Remote Testing Environment, Trusted UNICOS, UNICOS MAX, and UNICOS/mk are trademarks of Cray Research, Inc.

---

Silicon Graphics and the Silicon Graphics logo are registered trademarks and Origin and Origin2000 are trademarks of Silicon Graphics, Inc.

---

UNIX is a registered trademark in the United States and other countries, licensed exclusively through X/Open Company Limited.

---

Requests for copies of Cray Research, Inc. publications should be directed to:

CRAY RESEARCH, INC.  
Customer Service Logistics  
1100 Lowater Road  
P.O. Box 4000  
Chippewa Falls, WI 54729-0078  
USA

---

Comments about this publication should be directed to:

CRAY RESEARCH, INC.  
Service Publications and Training  
890 Industrial Blvd.  
P.O. Box 4000  
Chippewa Falls, WI 54729-0078  
USA

---

# SCE INTERFACE REFERENCE

Description of this Document .....	4
Interface Components .....	5
Base Window Title .....	6
Version Number .....	6
Simulator Indicator .....	6
Copy Number .....	6
Menu Bar .....	6
System Information Parameters .....	6
Physical Partition Parameters .....	7
Logical Partition Parameters .....	8
Status Information .....	10
Menu Button Commands .....	11
File -> Load .....	11
File -> Save .....	13
File -> Delete .....	14
File -> New -> Tester .....	15
File -> New -> T94 .....	15
File -> New -> T916 .....	15
File -> New -> T932 .....	15
File -> Print .....	16
How to Print the Configuration Data to a File .....	16
How to Print the Configuration Data to the Printer .....	16
View -> Memory .....	17
Module Type Parameters .....	17
Memory Degradation Parameters .....	20
Memory Partition Parameters .....	29
View -> CPUs .....	33
View -> Shareds .....	36
View -> I/Os .....	41
View -> Networks .....	44

View -> Channels .....	46
LOSP Channel Configuration Parameters .....	46
HISP Channel Configuration Parameters .....	49
VHISP Channel Configuration Parameters .....	51
GigaRing Channel Parameters .....	54
View -> Miscellaneous .....	56
View -> Spare Chip .....	59
View -> Log .....	60
Edit -> Reset Configuration .....	60
Edit -> Properties .....	61
Sparechip Directory Field .....	61
Sequence Save Settings .....	61
Debug Level Settings .....	62
Current Working Directory .....	62
Utilities -> Boundary Scan .....	63
Assume -> Physical Partition 0 .....	65
Assume -> Physical Partition 1 .....	65
Assume -> Both Partitions .....	65
Assert -> Physical Partition 0 .....	65
Assert -> Physical Partition 1 .....	67
Assert -> Both Partitions .....	68
Reset -> Maintenance Channel -> Physical Partition 0 .....	69
Reset -> Maintenance Channel -> Physical Partition 1 .....	69
Reset -> Error Logger Channel -> Physical Partition 0 .....	69
Reset -> Error Logger Channel -> Physical Partition 1 .....	69
Reset -> Boundary Scan Channel -> Physical Partition 0 .....	69
Reset -> Boundary Scan Channel -> Physical Partition 1 .....	70

## Figures

---

Figure 1.	Interface Components .....	5
Figure 2.	Memory Utilization Map .....	27
Figure 3.	Correlation of Bit Settings to Address Bits .....	28
Figure 4.	Configuration Verification Errors Detected .....	66
Figure 5.	Menu Quick Reference .....	71

## Tables

---

Table 1.	System Information Parameter Descriptions .....	7
Table 2.	Physical Partition Parameter Descriptions .....	7
Table 3.	Logical Partition Parameter Descriptions .....	8
Table 4.	Memory Module Type Parameters .....	18
Table 5.	General Memory Degradation Parameters .....	23
Table 6.	Default Mode Memory Degradation Parameters ...	24
Table 7.	Custom Mode Memory Degradation Parameters ...	26
Table 8.	Memory Partition Parameters .....	30
Table 9.	CPU Parameters .....	33
Table 10.	Shared Module Parameters .....	37
Table 11.	CRAY T94 Shared Module Ports and CPUs .....	38
Table 12.	CRAY T916 Shared Module Ports and CPUs .....	39
Table 13.	CRAY T932 Shared Module Ports and CPUs .....	40
Table 14.	I/O Parameters .....	42
Table 15.	Network Module Parameters .....	45
Table 16.	LOSP Parameters .....	47
Table 17.	HISP Parameters .....	49
Table 18.	VHISP Parameters .....	51
Table 19.	GigaRing Parameters .....	55
Table 20.	TSM Channel Parameters .....	57
Table 21.	SSD Parameters .....	58
Table 22.	Buttons That Display Boundary Scan Test Results .	64

## Description of this Document

---

This document is a reference for the user interface of the System Configuration Environment (SCE) application that configures CRAY T90™ series mainframes. This document describes the SCE interface and all available menu button commands. Figure 5 on page 71 shows all available menu button commands and indicates the pages in this document that describe the commands.

This document is one component of the SCE documentation set, which also includes the following document:

*SCE User Guide*, publication number HDM-069-C.

The *SCE User Guide* describes how to use SCE to configure CRAY T90 series mainframes.

## Interface Components

Figure 1 shows the components of the interface contained in the SCE base window. The paragraphs that follow the figure describe the components of the interface.




Figure 1. Interface Components

**NOTE:** Parameters are not updated until you choose a command from the **Assume**, **Apply**, or **Assert** menu button.

## Base Window Title

The base window title displays the name of the program: System Configuration Environment.

## Version Number

The version number indicates which version of SCE you are using.








## Simulator Indicator


When SCE is running with the mainframe simulator (MSIM), the simulator indicator displays SIM and the name of the workstation on which MSIM is running.

## Copy Number

The copy number indicates the copy of SCE that you are using. To set the copy number, start SCE with the `-copy` option. If you start SCE with the default copy number of 0, the SCE base window does not display a copy number. For more information about starting SCE with the `-copy` option, refer to the *SCE User Guide*, publication number HDM-069-C.

## Menu Bar

The menu bar contains seven menu buttons: , , , , , , and . For descriptions of the commands that are accessible from these menu buttons, refer to “Menu Button Commands” on page 11.

**NOTE:** The  button has been removed from the interface. Choose **Edit → Properties** to access the SCE T90: Properties window.

## System Information Parameters

The system information parameters define general system information. Table 1 describes the system parameters.



Table 1. System Information Parameter Descriptions

Parameter	Description
System Type	Mainframe type (This is set by the type you choose with the File → New command.)
System Serial	Mainframe serial number
System Memory	Total amount of memory in the mainframe
Physical Partitions	Number of physical partitions in the mainframe  <b>NOTE:</b> CRAY T94™ and CRAY T916™ mainframes can have only one physical partition.

### Physical Partition Parameters

The physical partition parameters define the physical partition configuration information. Table 2 describes the physical partition parameters.

Table 2. Physical Partition Parameter Descriptions

Parameter	Description
Current Physical Partition	Physical partition that you are currently configuring
Sanity Port	Maintenance port that SCE uses to access the sanity tree  This setting is used for CRAY T932™ mainframes, which have two maintenance ports.
Sparechips	Specifies whether spare chips will be used for the current physical partition
Logical Partitions	Number of logical partitions that you want to configure in the current physical partition  <b>NOTE:</b> Changing the number of logical partitions resets all current logical partition parameter settings. Make sure you select the proper number of logical partitions before you enter any logical partition parameter settings.

**NOTE:** The parameters that you use to configure the CRAY T90 series support multiplexer (TSM) channels have moved from the base window to the SCE T90: Miscellaneous Configuration window. You can access this window with the View → Miscellaneous command. Refer to “View → Miscellaneous” on page 56 for more information.

## Logical Partition Parameters

The logical partition parameters define the logical partition configuration information. Table 3 describes the logical partition parameters.

Table 3. Logical Partition Parameter Descriptions

Parameter	Description
Current Logical Partition	Logical partition you are currently configuring
Memory	<p>Amount of memory allocated to the current logical partition:</p> <p>SCE automatically sets this value based on the total memory, the number of logical partitions, and any memory degrades that have been indicated.</p> <p>This value adjusts immediately when you change the number of physical or logical partitions.</p>
Owner	<p>Owner of the partition:</p> <p>An operating system (OS) owner indicates that the logical partition is running an OS.</p> <p>A maintenance system (MS) owner indicates that you will perform maintenance activities in the logical partition. No OS-based user activity can use this logical partition.</p> <p><b>NOTE:</b> Ensure that the Owner setting is set to OS whenever the operating system is running in the mainframe. If you run the operating system in a partition that is owned by the maintenance system, the OS will crash if you start MME. (MME cannot be started in a partition that is owned by the OS.)</p>
Maintenance	<p>Type of maintenance allowed for an OS-owned partition:</p> <p>Use these settings to enable online and concurrent maintenance for the partition.</p>
Description	<p>Description of the current logical partition:</p> <p>Use this field to describe the current logical partition.</p>
CPUs	<p>CPUs configured for the current logical partition:</p> <p>Click on a CPU to select or deselect it. If you select a CPU that is already configured in a different logical partition, SCE removes the CPU from that logical partition and configures it into the current logical partition.</p>

Table 3. Logical Partition Parameter Descriptions (continued)

Parameter	Description
Cluster Offset	<p>First physical cluster contained in the current logical partition:</p> <p>This is logical cluster 1 for the current logical partition. This cluster appears as cluster 1 to the CPU.</p>
Cluster Range	<p>Number of shared clusters in the current logical partition:</p> <p>SCE uses this value and the cluster offset value to determine the range of clusters that the current logical partition contains.</p> <p>For example, if the cluster offset is 2 and the cluster range is 3, the current logical partition contains physical clusters 2, 3, and 4, which correspond to logical clusters 1, 2, and 3 for the current logical cluster. Numbering starts with logical cluster 1 because all logical partitions contain a logical cluster 0.</p> <p>If only one logical partition exists in the current physical partition, SCE sets this parameter to <math>22_8</math> and the Cluster Offset parameter to 1.</p> <p>If more than one logical partition exists in the current physical partition, SCE automatically sets this value to the number of CPUs in the logical partition plus 1.</p> <p><b>NOTE:</b> Clusters should not overlap logical partitions.</p>
Auto BCD	<p>Enables or disables the automatic broadcast cluster detach (auto BCD) function for CPUs in the current logical partition:</p> <p>If auto BCD is enabled (on), a CPU automatically detaches from a cluster when an exchange sequence occurs, which emulates normal CRAY C90 series mainframe operation mode.</p> <p>If auto BCD is disabled (off), an explicit function must execute to detach a CPU from its current cluster, which enables a CPU to attach to several clusters simultaneously.</p>
LOSPs	<p>LOSP channel pairs configured for the current logical partition:</p> <p>Click on a LOSP channel pair to select or deselect it. If you select a LOSP channel pair that is already configured in a different logical partition, SCE removes the LOSP channel pair from that logical partition and configures it into the current logical partition.</p> <p><b>NOTE:</b> All LOSP settings appear gray if you do not select any IO01 modules in the SCE T90: I/O Configuration window (for example, if you select the GigaRing™ setting for all IO modules in the system).</p>

Table 3. Logical Partition Parameter Descriptions (continued)

Parameter	Description
HISPs	<p>HISP channels configured for the current logical partition:</p> <p>Click on a HISP channel to select or deselect it. If you select a HISP channel that is already configured in a different logical partition, SCE removes the HISP channel from that logical partition and configures it into the current logical partition.</p> <p><b>NOTE:</b> All HISP settings appear gray if you do not select any IO01 modules in the SCE T90: I/O Configuration window (for example, if you select the GigaRing setting for all IO modules in the system).</p>
VHISPs	<p>VHISP channels configured for the current logical partition:</p> <p>Click on a VHISP channel to select or deselect it. If you select a VHISP channel that is already configured in a different logical partition, SCE removes the VHISP channel from that logical partition and configures it into the current logical partition.</p> <p><b>NOTE:</b> All VHISP settings appear gray if you do not select any IO01 modules in the SCE T90: I/O Configuration window (for example, if you select the GigaRing setting for all IO modules in the system).</p>

## Status Information

The status information indicates the current status of a configuration.


## Menu Button Commands

The menu buttons contain commands that manipulate SCE. This subsection describes the function of each command and how to use it. Figure 5 on page 71 shows all available menu button commands.

### File → Load



The File → Load command, as shown at the left, enables you to load a previously saved configuration file. This command displays the SCE T90: Load/Save (*directory*) window:



Perform the following procedure to manipulate this window:

1. Change the directory in the Load Dir field, if necessary, and press the Return key.

SCE appends the directory in the Load Dir field to the directory shown in parentheses (`/cri/cme/t32` in the example window shown) to determine the actual directory that SCE uses to load a file.

2. In the Load Files scroll box, click on the configuration file that you want to load.


The File field displays the complete pathname for the file. The Modified field displays the date on which the configuration file was last modified.

3. Click on . SCE loads the specified file.

**NOTE:** You can also load a file by double-clicking on the file in the Load Files scroll box.

**File → Save**

The File → Save command, as shown at the left, enables you to save the current configuration parameters in a file. This command displays the SCE T90: Load/Save (*directory*) window:



Perform the following procedure to manipulate this window:


1. To change the directory on the maintenance workstation (MWS) or system workstation (SWS) where the configuration file is saved, specify a different directory in the Save Dir field, and press the Return key.

SCE appends the directory in the Save Dir field to the directory shown in parentheses (`/cri/cme/t32` in the example window shown) to determine the actual directory that SCE uses to save a file.

2. In the Save File field, enter the name of the file you want to save, and press the Return key.
3. Click on  or press the Return key; SCE saves the specified configuration file.


**File → Delete**

The File → Delete command, as shown at the left, enables you to delete files that you no longer need. This command displays the SCE T90: Delete window:




**NOTE:** On an MWS, you can delete files that are located in the /cri/cme/t32/usr/ directory structure only. On an SWS, you can delete files that are located in the /opt/CYRIdiag/t32/usr/ directory structure only.


Perform the following procedure to manipulate this window:

1. Change the directory in the Directory field, if necessary, and press the Return key.
2. Click on the file(s) that you want to delete.
3. Click on ; SCE deletes the file(s).




**File → New → Tester**


The File → New → Tester command, as shown at the left, creates a default set of parameters to configure a CP module tester.

**File → New → T94**

The File → New → T94 command, as shown at the left, creates a default set of parameters to configure a CRAY T94 mainframe.

**File → New → T916**


The File → New → T916 command, as shown at the left, creates a default set of parameters to configure a CRAY T916 mainframe.

**File → New → T932**

The File → New → T932 command, as shown at the left, creates a default set of parameters to configure a CRAY T932 mainframe.

**File → Print**

The File → Print command, as shown at the left, enables you to print the current configuration data to the printer or to a file. This command displays the SCE T90: Print window:

**How to Print the Configuration Data to a File**

1. Click on Destination:  File.
2. In the Directory field, change the name of the directory to which SCE should print the file, if necessary. Press the Return key.
3. In the File field, enter the name of the file to which SCE should print the configuration data. Press the Return key.
4. Click on .

**How to Print the Configuration Data to the Printer**

1. Click on Destination:  Printer.
2. In the Command field, change the UNIX® command to print the file, if necessary.
3. Click on .

## View → Memory



The View → Memory command, as shown at the left, enables you to configure the parameters for the memory modules. This command displays the SCE T90: Memory Configuration window.

You can configure three different memory characteristics with this window: module types, memory degradations, and memory partitions. The Configure settings specify which characteristic the window will display. The following subsections describe the parameters that you use to configure these three memory characteristics.

### Module Type Parameters

Click on Configure: **Modules** to access the module configuration parameters. The window changes as shown in the following snap:




Table 4 describes the memory module type parameters.

Table 4. Memory Module Type Parameters


Parameter	Description																
Configure	Specifies which memory characteristic you want to configure (module types, memory degradations, or memory partitions)																
Physical Partition	Specifies the physical partition for which you want to modify the memory module type parameters																
Memory Type	<p>Specifies the type of memory modules that are in the mainframe. This parameter can have the following values:</p> <table border="0"> <thead> <tr> <th data-bbox="457 674 808 716"><b>Value:</b></th> <th data-bbox="808 674 1338 716"><b>Description:</b></th> </tr> </thead> <tbody> <tr> <td data-bbox="457 737 808 800">CM02 – Homogeneous</td> <td data-bbox="808 737 1338 800">The mainframe contains only CM02 modules.</td> </tr> <tr> <td data-bbox="457 831 808 894">CM03 – Homogeneous</td> <td data-bbox="808 831 1338 894">The mainframe contains only CM03 modules.</td> </tr> <tr> <td data-bbox="457 926 808 989">CM04 Homogeneous</td> <td data-bbox="808 926 1338 989">The mainframe contains only CM04 modules.</td> </tr> <tr> <td data-bbox="457 1020 808 1157">CM02/CM03 Mix</td> <td data-bbox="808 1020 1338 1157">The mainframe contains CM02 and CM03 modules. (This value appears when you choose CM02 for some modules and CM03 for other modules.)</td> </tr> <tr> <td data-bbox="457 1188 808 1325">CM02/CM04 Mix</td> <td data-bbox="808 1188 1338 1325">The mainframe contains CM02 and CM04 modules. (This value appears when you choose CM02 for some modules and CM04 for other modules.)</td> </tr> <tr> <td data-bbox="457 1356 808 1493">CM03/CM04 Mix</td> <td data-bbox="808 1356 1338 1493">The mainframe contains CM02 and CM03 modules. (This value appears when you choose CM02 for some modules and CM03 for other modules.)</td> </tr> <tr> <td data-bbox="457 1524 808 1696">Unsupported/Unknown</td> <td data-bbox="808 1524 1338 1696">The configuration that you are trying to create is not supported. (For example, if you try to create a configuration that contains CM02, CM03, and CM04, SCE displays the Unsupported/Unknown message.)</td> </tr> </tbody> </table>	<b>Value:</b>	<b>Description:</b>	CM02 – Homogeneous	The mainframe contains only CM02 modules.	CM03 – Homogeneous	The mainframe contains only CM03 modules.	CM04 Homogeneous	The mainframe contains only CM04 modules.	CM02/CM03 Mix	The mainframe contains CM02 and CM03 modules. (This value appears when you choose CM02 for some modules and CM03 for other modules.)	CM02/CM04 Mix	The mainframe contains CM02 and CM04 modules. (This value appears when you choose CM02 for some modules and CM04 for other modules.)	CM03/CM04 Mix	The mainframe contains CM02 and CM03 modules. (This value appears when you choose CM02 for some modules and CM03 for other modules.)	Unsupported/Unknown	The configuration that you are trying to create is not supported. (For example, if you try to create a configuration that contains CM02, CM03, and CM04, SCE displays the Unsupported/Unknown message.)
<b>Value:</b>	<b>Description:</b>																
CM02 – Homogeneous	The mainframe contains only CM02 modules.																
CM03 – Homogeneous	The mainframe contains only CM03 modules.																
CM04 Homogeneous	The mainframe contains only CM04 modules.																
CM02/CM03 Mix	The mainframe contains CM02 and CM03 modules. (This value appears when you choose CM02 for some modules and CM03 for other modules.)																
CM02/CM04 Mix	The mainframe contains CM02 and CM04 modules. (This value appears when you choose CM02 for some modules and CM04 for other modules.)																
CM03/CM04 Mix	The mainframe contains CM02 and CM03 modules. (This value appears when you choose CM02 for some modules and CM03 for other modules.)																
Unsupported/Unknown	The configuration that you are trying to create is not supported. (For example, if you try to create a configuration that contains CM02, CM03, and CM04, SCE displays the Unsupported/Unknown message.)																

Table 4. Memory Module Type Parameters (continued)

Parameter	Description
Memory	<p>Specifies the memory module for which you want to modify the configuration information (the Memory State and Type parameters).</p> <p>Settings 00, 01, 02, and 03 are valid for CRAY T94 mainframes.</p> <p>Settings 00, 01, 02, 03, 04, 05, 06, 07, 10, 11, 12, 13,14 15, 16, and 17 are valid for CRAY T916 mainframes.</p> <p>Settings 00, 01, 02, 03, 04, 05, 06, 07, 10, 11, 12, 13,14 15, 16, 17, 20, 21, 22, 23, 24, 25, 26, 27, 30, 31, 32, 33, 34, 35, 36, and 37 are valid for CRAY T932 mainframes.</p> <p>Use the All setting to specify that the modules are all one Type (either CM02, CM03, or CM04).</p>
Memory State	<p>Specifies the current state of the selected memory module:</p> <p>Working: Indicates that the module is installed in the mainframe and is operating correctly.</p> <p>Broken: Indicates that is installed in the mainframe, but the module is not operating correctly.</p> <p>Unavailable: Indicates that the selected module is not installed in the mainframe.</p>
Location	Indicates the slot location of the selected memory module.
Type	Specifies the type of the selected memory module: CM02, CM03, or CM04.

### Memory Degradation Parameters

Click on Configure: **Degrades** to access the memory degradation parameters. The window changes as shown in the following snap:



The memory degradation parameters enable you to perform memory degradation; for more information about memory degradation, refer to the *SCE User Guide*, publication number HDM-069-C.

Two versions of this window are available. If you click on Degrade Mode: **Default**, this window displays the default memory degradation parameters:


The screenshot shows a window titled "SCET90 Memory" with the following configuration options:

- Configure:** Modules, Degrades, Partitions
- Physical Partition:** 0
- Memory Type:** CM02 – Homogeneous
- Degrade Mode:** Default, Custom
- Sections:** All, 1/2, 0..7
- Subsections:** All, 1/2, 1/4, 1/8, 0, 1, 2, 3, 4, 5, 6, 7
- Banks:** All, 1/2, 1/4, 1/8, 0..7

The default memory degradation parameters present memory degradations as fractional components of the complete memory system. You can degrade sections to use half of the available sections. You can degrade subsections to use a half, a quarter, or an eighth of the available subsections. You can degrade banks to use a half, a quarter, an eighth, or a sixteenth (CRAY T94 mainframes with CM03 modules and CRAY T932 mainframes with CM03 modules only) of the available banks.

For examples of how to use default mode to perform memory degradation, refer to the *SCE User Guide*, publication number HDM-069-C.

If you click on Degrade Mode: **Custom**, this window displays the custom memory degradation parameters:



The custom memory degradation parameters enable you to perform memory degradations at the section level. You can change the parameters by choosing values from the abbreviated menu buttons or by clicking on the bits shown in the window.

For examples of how to use custom mode to perform memory degradation, refer to the *SCE User Guide*, publication number HDM-069-C.



Table 5 describes the memory configuration parameters that are available in both versions of the window. Table 6 describes the parameters that are available only in default mode. Table 7 describes the parameters that are available only in custom mode.

Table 5. General Memory Degradation Parameters

Parameter	Description																
Configure	Specifies which memory characteristic you want to configure (module types, memory degradations, or memory partitions)																
Physical Partition	Specifies the physical partition for which you want to modify the memory degradation parameters																
Memory Type	<p>Indicates the type of memory modules that are in the mainframe</p> <p>This read-only parameter displays the following messages:</p> <table border="0"> <thead> <tr> <th><b>Value:</b></th> <th><b>Description:</b></th> </tr> </thead> <tbody> <tr> <td>CM02 – Homogeneous</td> <td>The mainframe contains only CM02 modules.</td> </tr> <tr> <td>CM03 – Homogeneous</td> <td>The mainframe contains only CM03 modules.</td> </tr> <tr> <td>CM04 Homogeneous</td> <td>The mainframe contains only CM04 modules.</td> </tr> <tr> <td>CM02/CM03 Mix</td> <td>The mainframe contains CM02 and CM03 modules. (This value appears when you choose CM02 for some modules and CM03 for other modules.)</td> </tr> <tr> <td>CM02/CM04 Mix</td> <td>The mainframe contains CM02 and CM04 modules. (This value appears when you choose CM02 for some modules and CM04 for other modules.)</td> </tr> <tr> <td>CM03/CM04 Mix</td> <td>The mainframe contains CM02 and CM03 modules. (This value appears when you choose CM02 for some modules and CM03 for other modules.)</td> </tr> <tr> <td>Unsupported/Unknown</td> <td>The configuration that you are trying to create is not supported. (For example, if you try to create a configuration that contains CM02, CM03, and CM04, SCE displays the Unsupported/Unknown message.)</td> </tr> </tbody> </table>	<b>Value:</b>	<b>Description:</b>	CM02 – Homogeneous	The mainframe contains only CM02 modules.	CM03 – Homogeneous	The mainframe contains only CM03 modules.	CM04 Homogeneous	The mainframe contains only CM04 modules.	CM02/CM03 Mix	The mainframe contains CM02 and CM03 modules. (This value appears when you choose CM02 for some modules and CM03 for other modules.)	CM02/CM04 Mix	The mainframe contains CM02 and CM04 modules. (This value appears when you choose CM02 for some modules and CM04 for other modules.)	CM03/CM04 Mix	The mainframe contains CM02 and CM03 modules. (This value appears when you choose CM02 for some modules and CM03 for other modules.)	Unsupported/Unknown	The configuration that you are trying to create is not supported. (For example, if you try to create a configuration that contains CM02, CM03, and CM04, SCE displays the Unsupported/Unknown message.)
<b>Value:</b>	<b>Description:</b>																
CM02 – Homogeneous	The mainframe contains only CM02 modules.																
CM03 – Homogeneous	The mainframe contains only CM03 modules.																
CM04 Homogeneous	The mainframe contains only CM04 modules.																
CM02/CM03 Mix	The mainframe contains CM02 and CM03 modules. (This value appears when you choose CM02 for some modules and CM03 for other modules.)																
CM02/CM04 Mix	The mainframe contains CM02 and CM04 modules. (This value appears when you choose CM02 for some modules and CM04 for other modules.)																
CM03/CM04 Mix	The mainframe contains CM02 and CM03 modules. (This value appears when you choose CM02 for some modules and CM03 for other modules.)																
Unsupported/Unknown	The configuration that you are trying to create is not supported. (For example, if you try to create a configuration that contains CM02, CM03, and CM04, SCE displays the Unsupported/Unknown message.)																
Degrade Mode	Specifies that you want to perform memory degradation in default mode or custom mode																

Table 6. Default Mode Memory Degradation Parameters

Parameter	Description																		
Sections	<p>Degrades memory by sections:</p> <p>You can select to use All or 1/2 of the sections. If you use 1/2 of the sections, you can choose 0, 1, 2, 3 or 4, 5, 6, 7.</p>																		
Subsections	<p>Degrades memory by subsections:</p> <p>You can select to use all of the available subsections, one-half of the available subsections, one-quarter of the available subsections, or one-eighth of the available subsections.</p> <p>If you click on All, the memory configuration includes subsections 0 through 7.</p> <p>If you click on 1/2, you can select one of the following combinations:</p> <table data-bbox="483 787 974 850"> <tr> <td>0, 2, 4, 6</td> <td>0, 1, 4, 5</td> <td>0, 1, 2, 3</td> </tr> <tr> <td>1, 3, 5, 7</td> <td>2, 3, 6, 7</td> <td>4, 5, 6, 7</td> </tr> </table> <p>If you click on 1/4, you can select one of the following combinations:</p> <table data-bbox="483 945 730 1071"> <tr> <td>0, 4</td> <td>0, 2</td> <td>0, 1</td> </tr> <tr> <td>1, 5</td> <td>1, 3</td> <td>2, 3</td> </tr> <tr> <td>2, 6</td> <td>4, 6</td> <td>4, 5</td> </tr> <tr> <td>3, 7</td> <td>5, 7</td> <td>6, 7</td> </tr> </table> <p>If you click on 1/8, you can select any one subsection: 0, 1, 2, 3, 4, 5, 6, or 7.</p>	0, 2, 4, 6	0, 1, 4, 5	0, 1, 2, 3	1, 3, 5, 7	2, 3, 6, 7	4, 5, 6, 7	0, 4	0, 2	0, 1	1, 5	1, 3	2, 3	2, 6	4, 6	4, 5	3, 7	5, 7	6, 7
0, 2, 4, 6	0, 1, 4, 5	0, 1, 2, 3																	
1, 3, 5, 7	2, 3, 6, 7	4, 5, 6, 7																	
0, 4	0, 2	0, 1																	
1, 5	1, 3	2, 3																	
2, 6	4, 6	4, 5																	
3, 7	5, 7	6, 7																	
Banks	<p>Degrades memory by banks:</p> <p>You can select to use all of the available banks, one-half of the available banks, one-quarter of the available banks, one-eighth of the available banks, or one-sixteenth of the available banks (for CM03 and CM04 modules only).</p> <p><b>For CM02 Modules:</b></p> <p>If you click on All, the memory configuration includes banks 0 through 7.</p> <p>If you click on 1/2, you can select one of the following combinations:</p> <table data-bbox="483 1533 974 1596"> <tr> <td>0, 1, 2, 3</td> <td>0, 1, 4, 5</td> <td>0, 2, 4, 6</td> </tr> <tr> <td>4, 5, 6, 7</td> <td>2, 3, 6, 7</td> <td>1, 3, 5, 7</td> </tr> </table> <p>If you click on 1/4, you can select one of the following combinations:</p> <table data-bbox="483 1690 730 1816"> <tr> <td>0,1</td> <td>0,2</td> <td>0,4</td> </tr> <tr> <td>2,3</td> <td>1,3</td> <td>1,5</td> </tr> <tr> <td>4,5</td> <td>4,6</td> <td>2,6</td> </tr> <tr> <td>6,7</td> <td>5,7</td> <td>3,7</td> </tr> </table> <p>If you click on 1/8, you can select any one bank: 0, 1, 2, 3, 4, 5, 6, or 7.</p>	0, 1, 2, 3	0, 1, 4, 5	0, 2, 4, 6	4, 5, 6, 7	2, 3, 6, 7	1, 3, 5, 7	0,1	0,2	0,4	2,3	1,3	1,5	4,5	4,6	2,6	6,7	5,7	3,7
0, 1, 2, 3	0, 1, 4, 5	0, 2, 4, 6																	
4, 5, 6, 7	2, 3, 6, 7	1, 3, 5, 7																	
0,1	0,2	0,4																	
2,3	1,3	1,5																	
4,5	4,6	2,6																	
6,7	5,7	3,7																	

Table 6. Default Mode Memory Degradation Parameters (continued)

Parameter	Description																																																								
Banks (continued)	<p><b>For CM03 and CM04 modules:</b></p> <p>If you click on All, the memory configuration includes banks 0 through 16.</p> <p>If you click on 1/2, you can select one of the following combinations:</p> <p>0, 1, 2, 3, 4, 5, 6, 7  10, 11, 12, 13, 14, 15, 16, 17  0, 1, 2, 3, 10, 11, 12, 13  4, 5, 6, 7, 14, 15, 16, 17  0, 1, 4, 5, 10, 11, 14, 15  2, 3, 6, 7, 12, 13, 16, 17  0, 2, 4, 6, 10, 12, 14, 16  1, 3, 5, 7, 11, 13, 15, 17</p> <p>If you click on 1/4, you can select one of the following combinations:</p> <table data-bbox="483 869 1101 1121"> <tbody> <tr> <td>0, 1, 2, 3</td> <td>0, 2, 4, 6</td> <td>0, 2, 10, 12</td> </tr> <tr> <td>4, 5, 6, 7</td> <td>1, 3, 5, 7</td> <td>1, 3, 11, 13</td> </tr> <tr> <td>10, 11, 12, 13</td> <td>10, 12, 14, 16</td> <td>4, 6, 14, 16</td> </tr> <tr> <td>14, 15, 16, 17</td> <td>11, 13, 15, 17</td> <td>5, 7, 15, 17</td> </tr> <tr> <td>0, 1, 4, 5</td> <td>0, 1, 10, 11</td> <td>0, 4, 10, 14</td> </tr> <tr> <td>2, 3, 6, 7</td> <td>2, 3, 12, 13</td> <td>1, 5, 11, 15</td> </tr> <tr> <td>10, 11, 14, 15</td> <td>4, 5, 14, 15</td> <td>2, 6, 12, 16</td> </tr> <tr> <td>12, 13, 16, 17</td> <td>6, 7, 16, 17</td> <td>3, 7, 13, 17</td> </tr> </tbody> </table> <p>If you click on 1/8, you can select one of the following combinations:</p> <table data-bbox="483 1220 980 1472"> <tbody> <tr> <td>0, 1</td> <td>0, 2</td> <td>0, 4</td> <td>0, 10</td> </tr> <tr> <td>2, 3</td> <td>1, 3</td> <td>1, 5</td> <td>1, 11</td> </tr> <tr> <td>4, 5</td> <td>4, 6</td> <td>2, 6</td> <td>2, 12</td> </tr> <tr> <td>6, 7</td> <td>5, 7</td> <td>3, 7</td> <td>3, 13</td> </tr> <tr> <td>10, 11</td> <td>10, 12</td> <td>10, 14</td> <td>4, 14</td> </tr> <tr> <td>12, 13</td> <td>11, 13</td> <td>11, 15</td> <td>5, 15</td> </tr> <tr> <td>14, 15</td> <td>14, 16</td> <td>12, 16</td> <td>6, 16</td> </tr> <tr> <td>16, 17</td> <td>15, 17</td> <td>13, 17</td> <td>7, 17</td> </tr> </tbody> </table> <p>If you click on 1/16, you can select any one bank: 0, 1, 2, 3, 4, 5, 6, 7, 10, 11, 12, 13, 14, 15, 16, or 17.</p>	0, 1, 2, 3	0, 2, 4, 6	0, 2, 10, 12	4, 5, 6, 7	1, 3, 5, 7	1, 3, 11, 13	10, 11, 12, 13	10, 12, 14, 16	4, 6, 14, 16	14, 15, 16, 17	11, 13, 15, 17	5, 7, 15, 17	0, 1, 4, 5	0, 1, 10, 11	0, 4, 10, 14	2, 3, 6, 7	2, 3, 12, 13	1, 5, 11, 15	10, 11, 14, 15	4, 5, 14, 15	2, 6, 12, 16	12, 13, 16, 17	6, 7, 16, 17	3, 7, 13, 17	0, 1	0, 2	0, 4	0, 10	2, 3	1, 3	1, 5	1, 11	4, 5	4, 6	2, 6	2, 12	6, 7	5, 7	3, 7	3, 13	10, 11	10, 12	10, 14	4, 14	12, 13	11, 13	11, 15	5, 15	14, 15	14, 16	12, 16	6, 16	16, 17	15, 17	13, 17	7, 17
0, 1, 2, 3	0, 2, 4, 6	0, 2, 10, 12																																																							
4, 5, 6, 7	1, 3, 5, 7	1, 3, 11, 13																																																							
10, 11, 12, 13	10, 12, 14, 16	4, 6, 14, 16																																																							
14, 15, 16, 17	11, 13, 15, 17	5, 7, 15, 17																																																							
0, 1, 4, 5	0, 1, 10, 11	0, 4, 10, 14																																																							
2, 3, 6, 7	2, 3, 12, 13	1, 5, 11, 15																																																							
10, 11, 14, 15	4, 5, 14, 15	2, 6, 12, 16																																																							
12, 13, 16, 17	6, 7, 16, 17	3, 7, 13, 17																																																							
0, 1	0, 2	0, 4	0, 10																																																						
2, 3	1, 3	1, 5	1, 11																																																						
4, 5	4, 6	2, 6	2, 12																																																						
6, 7	5, 7	3, 7	3, 13																																																						
10, 11	10, 12	10, 14	4, 14																																																						
12, 13	11, 13	11, 15	5, 15																																																						
14, 15	14, 16	12, 16	6, 16																																																						
16, 17	15, 17	13, 17	7, 17																																																						

Table 7. Custom Mode Memory Degradation Parameters

Parameter	Description
Show Map	This button displays a graphical representation of the current memory utilization. Figure 2 on page 27 shows an example.
Sections	<p>Specifies the memory sections to use:</p> <p>Choose the memory sections that you want to use from the Sections abbreviated menu button.</p> <p>You can also change the selected sections by clicking on the bits that are shown. Figure 3 on page 28 shows how these bit settings correspond to the section bits in the address bits.</p> <p>These bits set the section profile and select bits. Each bit in this window can have one of three values [a dash (-), a 0, or a 1]:</p> <p style="padding-left: 40px;">The dash (-) sets the profile bit to 0 and the select bit to 0.  The 0 sets the profile bit to 1 and the select bit to 0.  The 1 sets the profile bit to 1 and the select bit to 1.</p>
Subsections	<p>Specifies the memory subsections to use:</p> <p>Choose the memory subsections that you want to use from the Subsections abbreviated menu button.</p> <p>In custom mode, you can set the subsections that you want to use for each section (for example, you could have one section use only subsections 0 through 3 and another section use only subsections 4 through 7. To do this, you choose the appropriate value from the abbreviated menu button next to the section that you want to change.</p> <p>You can also change the selected subsections by clicking on the bits that are shown next to the abbreviated menu buttons. Figure 3 on page 28 shows how these bit settings correspond to the subsection bits in the address bits.</p> <p>These bits set the subsection profile and select bits. Each bit in this window can have one of three values [a dash (-), a 0, or a 1]:</p> <p style="padding-left: 40px;">The dash (-) sets the profile bit to 0 and the select bit to 0.  The 0 sets the profile bit to 1 and the select bit to 0.  The 1 sets the profile bit to 1 and the select bit to 1.</p>

Table 7. Custom Mode Memory Degradation Parameters (continued)

Parameter	Description
Banks	<p>Specifies the memory banks to use:</p> <p>Choose the memory subsections that you want to use from the Banks abbreviated menu button.</p> <p>In custom mode, you can set the banks that you want to use for each section (for example, you could have one section use only banks 0 through 3 and another section use only banks 4 through 7. To do this, you choose the appropriate value from the abbreviated menu button next to the section that you want to change.</p> <p>You can also change the selected banks by clicking on the bits that are shown next to the abbreviated menu buttons. Figure 3 on page 28 shows how these bit settings correspond to the bank bits in the address bits.</p> <p>These bits set the bank profile and select bits. Each bit in this window can have one of three values [a dash (-), a 0, or a 1]:</p> <p style="padding-left: 40px;">The dash (-) sets the profile bit to 0 and the select bit to 0.                      The 0 sets the profile bit to 1 and the select bit to 0.                      The 1 sets the profile bit to 1 and the select bit to 1.</p>




Figure 2. Memory Utilization Map





Figure 3. Correlation of Bit Settings to Address Bits

## Memory Partition Parameters

Click on Configure: **Partitions** to access the memory partition parameters. The window changes as shown in the following snap:



This window enables you to change the memory groups that SCE assigns to the logical partition in the configuration.

Table 8 describes the memory partition parameters.

Table 8. Memory Partition Parameters

Parameter	Description																
Configure	Specifies which memory characteristic you want to configure (module types, memory degradations, or memory partitions)																
Physical Partition	Specifies the physical partition for which you want to modify the memory partition parameters																
Memory Type	<p>Indicates the type of memory modules that are in the mainframe</p> <p>This read-only parameter displays the following messages:</p> <table border="0"> <thead> <tr> <th data-bbox="477 611 808 642"><b>Value:</b></th> <th data-bbox="867 611 1430 642"><b>Description:</b></th> </tr> </thead> <tbody> <tr> <td data-bbox="477 674 808 705">CM02 – Homogeneous</td> <td data-bbox="867 674 1430 737">The mainframe contains only CM02 modules.</td> </tr> <tr> <td data-bbox="477 768 808 800">CM03 – Homogeneous</td> <td data-bbox="867 768 1430 831">The mainframe contains only CM03 modules.</td> </tr> <tr> <td data-bbox="477 863 808 894">CM04 Homogeneous</td> <td data-bbox="867 863 1430 894">The mainframe contains only CM04 modules.</td> </tr> <tr> <td data-bbox="477 926 808 957">CM02/CM03 Mix</td> <td data-bbox="867 926 1430 1052">The mainframe contains CM02 and CM03 modules. (This value appears when you choose CM02 for some modules and CM03 for other modules.)</td> </tr> <tr> <td data-bbox="477 1083 808 1115">CM02/CM04 Mix</td> <td data-bbox="867 1083 1430 1209">The mainframe contains CM02 and CM04 modules. (This value appears when you choose CM02 for some modules and CM04 for other modules.)</td> </tr> <tr> <td data-bbox="477 1241 808 1272">CM03/CM04 Mix</td> <td data-bbox="867 1241 1430 1367">The mainframe contains CM02 and CM03 modules. (This value appears when you choose CM02 for some modules and CM03 for other modules.)</td> </tr> <tr> <td data-bbox="477 1398 808 1430">Unsupported/Unknown</td> <td data-bbox="867 1398 1430 1566">The configuration that you are trying to create is not supported. (For example, if you try to create a configuration that contains CM02, CM03, and CM04, SCE displays the Unsupported/Unknown message.)</td> </tr> </tbody> </table>	<b>Value:</b>	<b>Description:</b>	CM02 – Homogeneous	The mainframe contains only CM02 modules.	CM03 – Homogeneous	The mainframe contains only CM03 modules.	CM04 Homogeneous	The mainframe contains only CM04 modules.	CM02/CM03 Mix	The mainframe contains CM02 and CM03 modules. (This value appears when you choose CM02 for some modules and CM03 for other modules.)	CM02/CM04 Mix	The mainframe contains CM02 and CM04 modules. (This value appears when you choose CM02 for some modules and CM04 for other modules.)	CM03/CM04 Mix	The mainframe contains CM02 and CM03 modules. (This value appears when you choose CM02 for some modules and CM03 for other modules.)	Unsupported/Unknown	The configuration that you are trying to create is not supported. (For example, if you try to create a configuration that contains CM02, CM03, and CM04, SCE displays the Unsupported/Unknown message.)
<b>Value:</b>	<b>Description:</b>																
CM02 – Homogeneous	The mainframe contains only CM02 modules.																
CM03 – Homogeneous	The mainframe contains only CM03 modules.																
CM04 Homogeneous	The mainframe contains only CM04 modules.																
CM02/CM03 Mix	The mainframe contains CM02 and CM03 modules. (This value appears when you choose CM02 for some modules and CM03 for other modules.)																
CM02/CM04 Mix	The mainframe contains CM02 and CM04 modules. (This value appears when you choose CM02 for some modules and CM04 for other modules.)																
CM03/CM04 Mix	The mainframe contains CM02 and CM03 modules. (This value appears when you choose CM02 for some modules and CM03 for other modules.)																
Unsupported/Unknown	The configuration that you are trying to create is not supported. (For example, if you try to create a configuration that contains CM02, CM03, and CM04, SCE displays the Unsupported/Unknown message.)																



Table 8. Memory Partition Parameters (continued)

Parameter	Description
Memory Group Parameters:	
Logical Partition 0	<p>Specifies the memory group for logical partition 0 (SCE defaults this to 0)</p> <p>You can set this parameter to None, 0, 1, 2, 3, or Custom.</p> <p>The Custom setting enables you to specify the values of the group profile and select bits. To change the values, click on the bit values under the 2<sup>1</sup> and 2<sup>0</sup> headings. Each bit can have one of three values [a dash (-), a 0, or a 1]:</p> <p style="padding-left: 40px;">The dash (-) sets the group profile bit to 0 and the group select bit to 0.</p> <p style="padding-left: 40px;">The 0 sets the group profile bit to 1 and the group select bit to 0.</p> <p style="padding-left: 40px;">The 1 sets the group profile bit to 1 and the group select bit to 1.</p>
Logical Partition 1	<p>Specifies the memory group for logical partition 1 (SCE defaults this to 1)</p> <p>You can set this parameter to None, 0, 1, 2, 3, or Custom.</p> <p>The Custom setting enables you to specify the values of the group profile and select bits. To change the values, click on the bit values under the 2<sup>1</sup> and 2<sup>0</sup> headings. Each bit can have one of three values [a dash (-), a 0, or a 1]:</p> <p style="padding-left: 40px;">The dash (-) sets the group profile bit to 0 and the group select bit to 0.</p> <p style="padding-left: 40px;">The 0 sets the group profile bit to 1 and the group select bit to 0.</p> <p style="padding-left: 40px;">The 1 sets the group profile bit to 1 and the group select bit to 1.</p>

Table 8. Memory Partition Parameters (continued)

Parameter	Description
Logical Partition 2	<p>Specifies the memory group for logical partition 2 (SCE defaults this to 2)</p> <p>You can set this parameter to None, 0, 1, 2, 3, or Custom.</p> <p>The Custom setting enables you to specify the values of the group profile and select bits. To change the values, click on the bit values under the 2<sup>^</sup>1 and 2<sup>^</sup>0 headings. Each bit can have one of three values [a dash (-), a 0, or a 1]:</p> <p style="padding-left: 40px;">The dash (-) sets the group profile bit to 0 and the group select bit to 0.</p> <p style="padding-left: 40px;">The 0 sets the group profile bit to 1 and the group select bit to 0.</p> <p style="padding-left: 40px;">The 1 sets the group profile bit to 1 and the group select bit to 1.</p>
Logical Partition 3	<p>Specifies the memory group for logical partition 3 (SCE defaults this to 3)</p> <p>You can set this parameter to None, 0, 1, 2, 3, or Custom.</p> <p>The Custom setting enables you to specify the values of the group profile and select bits. To change the values, click on the bit values under the 2<sup>^</sup>1 and 2<sup>^</sup>0 headings. Each bit can have one of three values [a dash (-), a 0, or a 1]:</p> <p style="padding-left: 40px;">The dash (-) sets the group profile bit to 0 and the group select bit to 0.</p> <p style="padding-left: 40px;">The 0 sets the group profile bit to 1 and the group select bit to 0.</p> <p style="padding-left: 40px;">The 1 sets the group profile bit to 1 and the group select bit to 1.</p>

**View → CPUs**



The View → CPUs command, as shown at the left, enables you to configure the parameters for the CP modules. This command displays the SCE T90: CPU Configuration window:




Table 9 describes the available CPU parameters.

Table 9. CPU Parameters

Parameter	Description
CPU	Specifies the CPU for which you want to modify parameters
CPU State	Specifies whether the CP module is working, broken, or unavailable:  Working: Indicates that the CP module is physically present and in working condition (The CP module can perform processing and can control I/O functions.)

Table 9. CPU Parameters (continued)

Parameter	Description
CPU State (continued)	<p>Broken: Indicates that the CP module is physically present but not in working condition (This setting specifies that the module cannot be used as a processor because a functional unit is broken, but it can control I/O functions.)</p> <p><b>NOTE:</b> Do not use the Broken setting if the CP module has memory/path problems. Use the Unavailable setting in this situation because the CP module cannot control I/O functions.</p> <p>Unavailable: Indicates that the CP module is not logically present (no processing or I/O functions are available.): either the CP module is not physically in the mainframe, or the CP module is so badly broken that it cannot control I/O functions.</p>
Route Code	Displays the route code to access the selected CP module
Location	Displays the physical location of the CP module (stack and slot)
CPU Type	<p>Specifies whether the CP module uses Cray Research, Inc. (CRAY) or IEEE floating-point number format:</p> <p>The CRI setting sets Major Revision to 2 and Minor Revision to 4. The IEEE setting sets Major Revision to 1 and Minor Revision to 0.</p>
Major Revision	Specifies the major revision level of the CP module
Minor Revision	Specifies the minor revision level of the CP module
Assigned	Indicates whether or not the CPU is assigned to a physical and logical partition
Physical Number	<p>Displays the physical number in the mainframe of the CP module:</p> <p>Do not change this number.</p>
Logical Number	<p>Specifies the logical number of the CP module:</p> <p>Do not change this number unless you use caution and have a thorough understanding of CRAY T90 series mainframe configuration.</p>
CPU Inverted	<p>Indicates the orientation of the CP module:</p> <p>Off: Indicates that the CP module is not inverted</p> <p>On: Indicates that the CP module is inverted</p> <p>When this parameter is set to On, SCE complements the section address before the address gets to the CI options.</p> <p>Only CRAY T916 and CRAY T932 mainframes can have inverted CP modules (in stacks F and N).</p>
Force CPU 256K	Forces the CPU to access only the upper 256 Kwords of memory (used for concurrent maintenance mode) when set to On

Table 9. CPU Parameters (continued)

Parameter	Description
Force I/O 256K	<p>Forces all I/O activity through this CPU to access only the upper 256 Kwords of memory (used for concurrent maintenance mode) when set to On</p> <p><b>NOTE:</b> This setting also affects direct memory access (DMA) transfers made with the maintenance channel through this CPU.</p>
Shared Access	Enables the CPU to access the shared module, which provides access to the clusters and semaphores
Originate I/O	Enables the CPU to initiate I/O activity
Pass Through I/O	<p>Enables I/O transfers to pass through this CPU when another CPU requests data from this CPU's channels</p> <p><b>NOTE:</b> Not all CPUs have channel access.</p>

**View → Shares**



The View → Shares command, as shown at the left, enables you to configure the parameters for the shared modules. This command displays the SCE T90: Shared Configuration window:

**SCE T90: Shared Configuration**

**Shared:**

**Shared State:**

**Route Code:** 00/00/00/00/00/00/20/30

**Location:** C1

**Major Revision:**  ▲▼

**Minor Revision:**  ▲▼

**Position:**

**Sanity Path:**     (From Root I/O to First Shared)

**Remote Sanity:**

---

**Port:**

0	1	2	3
4	5	6	7
10	11	12	13
14	15	16	17
20	21	22	23
24	25	26	27
30	31	32	33
34	35	36	37

**Logical CPU:**  ▲▼

**Cluster Group:**  ▲▼

**Cluster Offset:**  ▲▼

**Cluster Range:**  ▲▼

**Auto BCD:**

**I/O Group:**  ▲▼

**Timeout – Source:**

**Destination:**

---

**Cluster:**

01	02	03	04	05	06	07	10	11
12	13	14	15	16	17	20	21	22
23	24	25	26	27	30	31	32	33
34	35	36	37	40	41	42	43	44

**Cluster State:**

Table 10 describes the available shared module configuration parameters.

Table 10. Shared Module Parameters

Parameter	Description
Shared	Specifies the shared module for which you want to modify parameters
Shared State	Specifies whether the shared module is working, broken, or unavailable:  Working: Indicates that the shared module is physically present and in working condition  Broken: Indicates that the shared module is physically present but not in working condition  Unavailable: Indicates that the shared module is not logically present
Route Code	Displays the route code to access the selected shared module
Location	Displays the physical location of the shared module
Major Revision	Specifies the major revision level of the shared module
Minor Revision	Specifies the minor revision level of the shared module
Position	Specifies the physical location of the shared module in the mainframe (determines with which IO module the shared module communicates)
Sanity Path	Specifies the path (CP module) through which to route the sanity code from the IO module to the first shared module
Remote Sanity	Specifies the sanity path (primary or secondary [CRAY T932 systems only])
Port	Specifies the port for which you want to modify parameters. (Refer to Table 11, Table 12, and Table 13 to find out which shared module ports reference which CPUs.) You can set the following parameters for each port:  Logical CPU: Specifies the logical CPU number of the CP module. Do not change this unless you use caution and have a thorough understanding of CRAY T90 series mainframe configuration.  Cluster Group: Specifies which cluster group the CPU is in  Cluster Offset: Specifies the first physical cluster accessed by this port's associated CPU  Cluster Range: Specifies the number of clusters accessed by this port's associated CPU (For more information, refer to page 9.)

Table 10. Shared Module Parameters (continued)

Parameter	Description
Port (continued)	<p>Auto BCD: Enables or disables the automatic broadcast cluster detach option (For more information, refer to page 9.)</p> <p>I/O Group: Specifies which I/O group the CPU is in</p> <p>Timeout – Source: Specifies the source timer value for 033 instructions</p> <p>Destination: Specifies the destination timer value for 033 instructions</p>
Cluster	Specifies the cluster for which you want to modify parameters
Cluster State	Specifies whether the cluster is working or broken

Table 11. CRAY T94 Shared  
Module Ports and CPUs

Port	CPU
2	0
3	1
4	2
5	3



Table 12. CRAY T916 Shared Module Ports and CPUs

Shared Module	Port	CPU
0	0	0
0	1	1
0	2	2
0	3	3
0	4	4
0	5	5
0	6	6
0	7	7
0	10	10
0	11	11
0	12	12
0	13	13
0	14	14
0	15	15
0	16	16
0	17	17

Table 13. CRAY T932 Shared Module Ports and CPUs

Shared Module	Port	CPU
0	0	0
0	1	1
0	2	2
0	3	3
0	4	4
0	5	5
0	6	6
0	7	7
0	10	10
0	11	11
0	12	12
0	13	13
0	14	14
0	15	15
0	16	16
0	17	17
1	0	20
1	1	21
1	2	22
1	3	23
1	4	24
1	5	25
1	6	26
1	7	27
1	10	30
1	11	31
1	12	32
1	13	33
1	14	34
1	15	35
1	16	36
1	17	37

## View → I/Os



The View → I/Os command, as shown at the left, enables you to configure the parameters for the IO modules. This command displays the SCE T90: I/O Configuration window:

**SCE T90: I/O Configuration**

I/O:

I/O State:

Route Code: 00/00/00/00/00/00/00/30  
Location: A1

I/O Type:

Major Revision:

Minor Revision:

Position:

Sanity Path:     (From CPU to Leaf I/O)

Quadrant 0 State:

Quadrant 1 State:

Quadrant 2 State:

Quadrant 3 State:

MCU Interrupt: <<<<<<.....  
PINT Mask: <>>.....

Flow Control:

Target ID Location:

Primary I/O Group:

Secondary I/O Group:

Primary Memory Group:

Secondary Memory Group:

Remote Delay:    (msec)

Table 14 describes the available I/O configuration parameters.

Table 14. I/O Parameters

Parameter	Description
I/O	Specifies the IO module for which you want to modify parameters
I/O State	Specifies whether the IO module is working, broken, or unavailable:  Working: Indicates that the IO module is physically present and in working condition  Broken: Indicates that the IO module is physically present but not in working condition  Unavailable: Indicates that the IO module is not logically present
Route Code	Displays the route code used to access the selected IO module
Location	Displays the physical location of the IO module in the mainframe
I/O Type	Specifies the type of the selected IO module:  The Cray setting specifies that the module is an IO01 module. The GigaRing setting specifies that the module is an IO02 module.
Major Revision	Specifies the major revision level of the selected IO module
Minor Revision	Specifies the minor revision level of the selected IO module
Position	Specifies the logical position of the selected IO module, which determines the range of I/O channel numbers for the module:  This value biases the logical channel numbers. For example, if the module is configured as position 0, the module has VHISP channels 20, 21, 22, 23; if the module is configured as position 1, the module has VHISP channels 24, 25, 26, 27; etc.  Set Position to 0 for a CRAY T94 mainframe.  <b>NOTE:</b> This parameter is valid only for IO01 modules.
Sanity Path	Selects one of the four CP module pass-through ports through which the IO module sends data:  This setting specifies the first local CP module to turn sanity on to the IO module. For larger CRAY T90 series mainframes, this is important for the second, third, and fourth IO modules because it establishes the route codes to these IO modules. (This setting specifies which path is used to configure the IO module and return the error logger data.)  <b>NOTE:</b> This setting applies only to the leaf IO module in the sanity tree. For the root IO module, SCE enables sanity from the local CP modules to the IO module, but error logger data does not return on this path.
Quadrant 0 State	Specifies whether quadrant 0 is working, broken, or unavailable
Quadrant 1 State	Specifies whether quadrant 1 is working, broken, or unavailable

Table 14. I/O Parameters (continued)

Parameter	Description
Quadrant 2 State	Specifies whether quadrant 2 is working, broken, or unavailable
Quadrant 3 State	Specifies whether quadrant 3 is working, broken, or unavailable
MCU Interrupt	Specifies a value to load into the MCU interrupt register  <b>NOTE:</b> This parameter is valid only for IO01 modules.
PINT Mask	Specifies a value used to mask the I/O group bits sent by a PINT channel operation:  Any bit set to 0 in this mask prevents the PINT function from interrupting any CPU in the corresponding I/O channel group  <b>NOTE:</b> This parameter is valid only for IO01 modules.
Flow Control	Selects the handshaking protocol that is used for congestion control (determines what hardware controls the number of packets on the GigaRing nodes):  CS: Selects system congestion control  CC: Selects client congestion control (Do not enable this setting because the hardware currently does not support client congestion control.)  <b>NOTE:</b> This parameter is valid only for IO02 modules.
Target ID Location	Selects the bits in the GigaRing address that select the I/O group to use.  <b>NOTE:</b> This parameter is valid only for IO02 modules.
Primary I/O Group	Selects the primary I/O group to which the GigaRing node belongs. (This parameter defaults to 0. Do not change this parameter.) <b>NOTE:</b> This parameter is valid only for IO02 modules.
Secondary I/O Group	Selects the secondary I/O group to which the GigaRing node belongs. (This parameter defaults to 0. Do not change this parameter.)  <b>NOTE:</b> This parameter is valid only for IO02 modules.
Primary Memory Group	Selects the primary memory group to which the GigaRing node belongs. (This parameter defaults to 0. Do not change this parameter.)  <b>NOTE:</b> This parameter is valid only for IO02 modules.

Table 14. I/O Parameters (continued)

Parameter	Description
Secondary Memory Group	Selects the secondary group to which the GigaRing node belongs. (This parameter defaults to 0. Do not change this parameter.)  <b>NOTE:</b> This parameter is valid only for IO02 modules.
Remote Delay	Specifies the timeout delay (in milliseconds) on the DN option.  <b>NOTE:</b> This parameter is valid only for IO02 modules.

### View → Networks



The View → Networks command, as shown at the left, enables you to configure the network module parameters in CRAY T916 and CRAY T932 mainframes. This command displays the SCE T90: Network Configuration window:




Table 15 describes the available network module parameters.

Table 15. Network Module Parameters

Parameter	Description
Network	Selects the module for which you want to modify the Network State parameter
Network State	Specifies whether the network module is working, broken, or unavailable:  Working: Indicates that the network module is physically present and in working condition  Broken: Indicates that the network module is physically present but not in working condition  Unavailable: Indicates that the network module is not present
Location	Displays the physical location of the module in the mainframe

## View → Channels



The View → Channels command, as shown at the left, enables you to configure the channel parameters. This command displays the SCE T90: Channel Configuration window, which contains the configuration parameters for the LOSP, HISP, and VHISP channels.

### LOSP Channel Configuration Parameters

Click on Channel Type: **LOSP** to access the LOSP channel configuration parameters. The SCE T90: Channel Configuration window displays the LOSP parameters:




Table 16 describes the LOSP channel configuration parameters.



Table 16. LOSP Parameters

Parameter	Description
LOSP Channel	Selects the LOSP channel pair for which you want to modify parameters
SLOSP Channel	Selects the support LOSP (SLOSP) channel pair for which you want to modify parameters
State	Specifies whether the LOSP channel pair is working or broken
Logical Channel	Displays the logical channel numbers that SCE assigns to the LOSP channel pair
Assigned	Indicates whether or not the LOSP channel pair is assigned to a physical and logical partition
Physical Partition	Indicates the physical partition to which the LOSP channel pair is assigned
Logical Partition	Indicates the logical partition to which the LOSP channel pair is assigned
Control	Indicates whether the selected LOSP channel pair is On or Off:  The channel pair is logically turned off if you do not include it in a configuration (when you do not select it in the SCE base window).  The channel pair is logically turned on if you include it in a configuration (when you select it in the SCE base window).
I/O Group	Specifies the I/O group to which the LOSP channel pair is assigned:  These channels are isolated to the CPUs within this I/O group, and these channels can interrupt only CPUs in the same I/O group. These channels can accept commands only from CPUs in the same I/O group.
Memory Group	Specifies the memory group to which the LOSP channel pair is assigned
MISP	Specifies whether or not the channel should operate in MISP mode
256K	Specifies whether or not the LOSP channel pair is in 256-Kword mode (used for concurrent maintenance):  If the LOSP channel pair is in 256-Kword mode, data transfers are forced to the upper 256 Kwords of common memory.

Table 16. LOSP Parameters (continued)

Parameter	Description
Mode	<p>Specifies which mode the channel pair is running:</p> <p>External Device indicates that the LOSP channel pair is connected to an external device</p> <p>Loopback Internal indicates that the LOSP channel pair is looped back inside the mainframe chassis (on the module)</p> <p>Loopback External indicates that the channel is looped back through an external cable on the bulkhead: choose the channel to which the current LOSP channel is looped back.</p> <p>Open indicates that a channel is open: For example, if channel 100 is looped back to channel 103, you should set channel pair 102/103 to open because channel 102 is not connected.</p>
Support Path	<p>Specifies the CP module through which the support channel data is routed (Valid for SLOSP channels only)</p>

## HISP Channel Configuration Parameters

Click on Channel Type: **HISP** to access the HISP channel configuration parameters. The SCE T90: Channel Configuration window displays the HISP parameters:

The screenshot shows the 'SCE T90: Channel Configuration' window. At the top, there are four tabs: 'LOSP', 'HISP', 'VHISP', and 'GigaRing'. The 'HISP' tab is selected. Below the tabs, there is a section titled 'HISP Channel:' containing a table of channel numbers:

400	420
401	421
402	422
403	423
404	424
405	425
406	426
407	427
410	430
411	431
412	432
413	433
414	434
415	435
416	436
417	437

To the right of the table, there are several configuration options:

- State:** A dropdown menu with options: Working, Broken, Unavailable.
- Logical Channel:** 400
- Assigned:** Yes
- Physical Partition:** 0
- Logical Partition:** 0
- Control:** On
- Memory Group:** Off On (with a numeric keypad showing 1 and 2)
- 256k:** Off On

Table 17 describes the HISP channel configuration parameters.

Table 17. HISP Parameters

Parameter	Description
HISP Channel	Selects the HISP channel for which you want to modify parameters
State	Specifies whether the HISP channel is working or broken
Logical Channel	Displays the logical channel number that SCE assigns to the HISP channel
Assigned	Indicates whether or not the HISP channel is assigned to a physical partition and logical partition

Table 17. HISP Parameters (continued)

Parameter	Description
Physical Partition	Indicates the physical partition to which the HISP channel is assigned
Logical Partition	Indicates the logical partition to which the HISP channel is assigned
Control	<p>Indicates whether the selected HISP channel is On or Off:</p> <p>The channel is logically turned off if you do not include it in a configuration (when you do not select it in the SCE base window).</p> <p>The channel is logically turned on if you include it in a configuration (when you select it in the SCE base window).</p>
Memory Group	Specifies the memory group to which the HISP channel is assigned
256K	<p>Specifies whether or not the HISP channel is in 256-Kword mode (used for concurrent maintenance):</p> <p>If the HISP channel is in 256-Kword mode, data transfers are forced to the upper 256 Kwords of common memory.</p>

## VHISP Channel Configuration Parameters

Click on Channel Type: **VHISP** to access the VHISP channel configuration parameters. The SCE T90: Channel Configuration window displays the VHISP parameters:

The screenshot shows the 'SCE T90: Channel Configuration' window. At the top, 'Channel Type' is set to 'VHISP'. Below this, a table lists 'VHISP Channel' options from 020 to 037. To the right, the 'State' is 'Working'. Other parameters include 'Logical Channel: 020', 'Assigned: Yes', 'Physical Partition: 0', and 'Logical Partition: 0'. Control settings include 'Control: On', 'I/O Group: 0', 'Memory Group: Off', and '256K: Off'. Edge settings for '0/1 Edge' and '1/0 Edge' are both set to 'Odd'. Delay settings are 'Offset Delay: 0' and 'Capture Delay: 1'. A note at the bottom states: 'NOTE: SSD configuration in Miscellaneous Configuration popup.'

Table 18 describes the VHISP channel configuration parameters.

Table 18. VHISP Parameters

Parameter	Description
VHISP Channel	Selects the VHISP channel for which you want to modify parameters
State	Specifies whether or not the VHISP channel is working or broken
Logical Channel	Displays the logical channel number that SCE assigns to the VHISP channel
Assigned	Indicates whether or not the VHISP channel is assigned to a physical partition and a logical partition

Table 18. VHISP Parameters (continued)

Parameter	Description
Physical Partition	Indicates the physical partition to which the VHISP channel is assigned
Logical Partition	Indicates the logical partition to which the VHISP channel is assigned
Control	Indicates whether the selected VHISP channel is On or Off:  The channel is logically turned off if you do not include it in a configuration (when you do not select it in the SCE base window).  The channel is logically turned on if you include it in a configuration (when you select it in the SCE base window).
I/O Group	Specifies the I/O group to which the VHISP channel is assigned
Memory Group	Specifies the memory group to which the VHISP channel is assigned
256K	Specifies whether or not the VHISP channel is in 256-Kword mode (used for concurrent maintenance):  If the VHISP channel is in 256-Kword mode, data transfers are forced to the upper 256 Kwords of common memory.
Logic 0 Width	Specifies the number of clock periods the VHISP clock is 0  <b>Do not change this parameter. If you change this parameter, the mainframe could become unusable.</b>
Logic 1 Width	Specifies the number of clock periods the VHISP clock is 1  <b>Do not change this parameter. If you change this parameter, the mainframe could become unusable.</b>
0/1 Edge	Specifies when the 0/1 transition in the generated wave occurs:  If this parameter is set to odd, the 0/1 transition in the generated wave occurs on the 0/1 edge of the mainframe clock. If the parameter is set to even, the transition occurs 1/2-clock period earlier.  <b>Do not change this parameter. If you change this parameter, the mainframe could become unusable.</b>
1/0 Edge	Specifies when the 1/0 transition in the generated wave occurs:  If this parameter is set to odd, the 1/0 transition in the generated wave occurs on the 0/1 edge of the mainframe clock. If the parameter is set to even, the transition occurs 1/2-clock period earlier.  <b>Do not change this parameter. If you change this parameter, the mainframe could become unusable.</b>

Table 18. VHISP Parameters (continued)

Parameter	Description
Offset Delay	<p>Specifies a delay, in clock periods, for output data and control signals to be valid after the leading edge of the generated VHISP clock:</p> <p>This value is within a modulus of the generated VHISP clock period.</p> <p><b>Do not change this parameter. If you change this parameter, the mainframe could become unusable.</b></p>
Capture Delay	<p>Specifies a delay, in clock periods, after the leading edge of the input data ready strobe before data is captured in the channel input register:</p> <p>This delay is added to 4 clock periods.</p> <p><b>Do not change this parameter. If you change this parameter, the mainframe could become unusable.</b></p>

### GigaRing Channel Parameters

Click on Channel Type: **GigaRing** to access the GigaRing channel configuration parameters. The SCE T90: Channel Configuration window displays the GigaRing parameters:

**SCE T90: Channel Configuration**

Channel Type: LOSP HISP VHISP **GigaRing**

00 On	20 -
01 On	21 -
02 On	22 -
03 On	23 -
04 On	24 -
05 On	25 -
06 On	26 -
07 On	27 -
10 -	30 -
11 -	31 -
12 -	32 -
13 -	33 -
14 -	34 -
15 -	35 -
16 -	36 -
17 -	37 -

**State:** Working  
Broken  
Unavailable

**Control:** Off On

**Enabled Channels:** Error Channel A  
Error Channel B  
Input Message Channel A  
Input Message Channel B  
Output Message Channel  
DMA Channel

**On Time:** 0 1 2 3 **4** 5 6 7

**Off Time:** 0 1 2 3 **4** 5 6 7

**Input Offset:** 0 ▲▼

**Output Offset:** 1 ▲▼

**Manufacturer ID:** 0 ▲▼

**Device ID:** 0 ▲▼

Table 19 describes the GigaRing channel configuration parameters.



Table 19. GigaRing Parameters

Parameter	Description								
GigaRing Node	<p>Selects the GigaRing node for which you want to modify parameters</p> <p><b>NOTE:</b> The text that SCE displays in the GigaRing Node settings changes depending on the state of the node. SCE displays the following symbols in the GigaRing Node settings:</p> <table> <thead> <tr> <th>Symbol:</th> <th>Description:</th> </tr> </thead> <tbody> <tr> <td>On</td> <td>The node/channel is on.</td> </tr> <tr> <td>Off</td> <td>The node/channel is off.</td> </tr> <tr> <td>–</td> <td>The node/channel is not available.</td> </tr> </tbody> </table>	Symbol:	Description:	On	The node/channel is on.	Off	The node/channel is off.	–	The node/channel is not available.
Symbol:	Description:								
On	The node/channel is on.								
Off	The node/channel is off.								
–	The node/channel is not available.								
State	Specifies that the GigaRing node is working, broken, or unavailable								
Control	Specifies whether the GigaRing node is On or Off								
Enabled Channels	<p>Specifies which of the following channels are enabled (for diagnostic configuration): error channel A, error channel B, input message channel A, input message channel B, the output message channel, and the DMA Channel</p> <p>These channels are GigaRing subchannels that are used for diagnostic testing. By default, SCE enables these channels.</p>								
On Time	Specifies the number of phases that the GigaRing channel is on								
Off Time	Specifies the number of phases that the GigaRing channel is off								
Input Offset	Sets the input data offset register								
Output Offset	Sets the output data offset register								
Manufacturer ID	Sets the manufacturer ID register								
Device ID	Sets the device ID register								

## View → Miscellaneous



The View → Miscellaneous command, as shown at the left, enables you to set miscellaneous parameters. This command displays the SCE T90: Miscellaneous Configuration window:

**SCE T90: Miscellaneous Configuration**

Configure:

**Side A:** (CPUs 00..17, I/O 0 & 1, Shared 0)

Port:

MPN Hostname: 

Maintenance Channel: FEI:

Boundary Scan Channel: FEI:

Error Logger Channel: FEI:

Support Channel: FEI:  Input:

Output:

**Side B:** (CPUs 20..37, I/O 2 & 3, Shared 1)

Port:

MPN Hostname: 

Maintenance Channel: FEI:

Boundary Scan Channel: FEI:

Error Logger Channel: FEI:

Support Channel: FEI:  Input:

Output:


This window contains two sets of parameters: the CRAY T90 series support multiplexer (TSM) channel parameters and the SSD parameters. By default, this window displays the TSM channel parameters. Table 20 describes the TSM channel parameters.

**NOTE:** The Side A parameters are available for all mainframe configurations. The Side B parameters are available only for CRAY T932 mainframe configurations that include two physical partitions.

Table 20. TSM Channel Parameters

Parameter	Description
MPN Hostname	Specifies the hostname of the multipurpose node to which the SWS is connected in a GigaRing system  <b>NOTE:</b> This parameter is valid only for systems that use IO02 modules.
Maintenance Channel †	Front-end interface (FEI) channel and maintenance port to which the maintenance channel is connected  Choose the port from the corresponding Port menu.  <b>NOTE:</b> This parameter is valid only for systems that use IO01 modules.
Boundary Scan Channel †	FEI channel and port to which the boundary scan channel is connected  Choose the port from the corresponding Port menu.  <b>NOTE:</b> This parameter is valid only for systems that use IO01 modules.
Error Logger Channel †	FEI channel to which the error logger channel is connected  <b>NOTE:</b> This parameter is valid only for systems that use IO01 modules.
Support Channel †	FEI channel to which the support channel is connected and the channels used as input and output for the support channel  <b>NOTE:</b> This parameter is valid only for systems that use IO01 modules.

† The `xcfg` program configures this channel. You should set this parameter to the value specified in `xcfg`. SCE provides this information to other software applications, so you must set this parameter correctly. If you need to change the configuration information for this channel, update this parameter and the corresponding parameter in `xcfg`.

Click on Configure:  to access the SSD parameters. The window changes to display the SSD parameters, as shown in the following snap.




Table 21 describes the SSD parameters.


Table 21. SSD Parameters

Parameter	Description
Configure	Selects the miscellaneous parameters to configure:  Currently, SSD parameters are the only miscellaneous parameters available.
SSDs	Specifies the number of SSDs connected to the mainframe:  Currently, you can set this parameter to 0 or 1.
SSD	Specifies the SSD for which you want to change the parameters:  Click on the number of the SSD for which you want to change the parameters. Currently, you can change parameters for SSD number 0 only (when the SSDs parameter is set to 1).
SSD Type	Specifies the type of SSD
SSD Memory	Specifies the memory size of the SSD

## View → Spare Chip



The View → Spare Chip command, as shown at the left, enables you to control the spare chip functionality of the CRAY T90 series mainframe. This command displays the SCE T90: Spare Chip window:




For more information about using SCE to control the spare-chip functionality, refer to the *SCE User Guide*, publication number HDM-069-C.

### View → Log



The View → Log command, as shown at the left, enables you to view a log from the last application of a configuration. This command displays the SCE T90: Log Output window:




### Edit → Reset Configuration




The Edit → Reset Configuration command, as shown at the left, resets all parameters to the last applied configuration.

## Edit → Properties



The Edit → Properties command, as shown at the left, enables you to modify the way that SCE works. This command displays the SCE T90: Properties window:



The following subsections describe the properties that you can modify. Click on the  button to apply the new properties that you set. Click on the  button to reset the properties to the default values.

### Sparechip Directory Field

In the Sparechip Directory field, enter the directory in which you want to store the spare-chip data.

### Sequence Save Settings

Use the Sequence Save settings to enable the automatic save configuration function, which automatically saves the current sequence of maintenance channel functions in the `usr/seq/FASTT.serial#.z` file. Then, you can use compose mode in MME environment 0 to view the sequence.

Click on  **Always** to save the sequence every time SCE builds the sequence while asserting a configuration. Click on  **On Error** to save the sequence only when SCE detects errors in the sequence while asserting the configuration. Click on  **Never** to never save the sequence.

## Debug Level Settings

Use the Debug Level settings to specify the type of information that SCE should display in the standard output window.

Click on  **None** to indicate that SCE should not display information about the actions that it performs.

Click on  **Internals** to have SCE display spare-chip information, client connections and disconnections, and information about other SCE internal functions.

**NOTE:** When you are using spare memory chips, you should set the Debug Level setting to  **Internals**. This causes SCE to display the flaw map in the standard output window when you assert a configuration. By viewing the flaw map during an assertion, you will see any errors related to the spare chip assignment. For example, if you enter 2 flaws in the same stack (which invalidates the first flaw), SCE will not display an error until you assert the configuration.

Click on  **Channel Functions** to have SCE display the functions that are sent to the mainframe and the information displayed for the  **Internals** setting.

## Current Working Directory

The Current Working Directory field shows the directory that SCE uses to access all relative paths (paths that do not start with a slash [/]) shown in SCE windows. SCE appends all relative paths to this directory. For example, if a window displays `usr/cfg` and this field displays `/cri/cme/t32`, SCE uses the `/cri/cme/t32/usr/cfg/` directory to access files. This field is read-only.

The information in this field is useful in the Systems Test and Checkout (STCO) environment in which technicians have access to remotely mounted directories of prereleased software. This information enables a technician to verify the paths that are used to load and save files so the technician can ensure that the proper software is being used.



## Utilities → Boundary Scan



The Utilities → Boundary Scan command, as shown at the left, provides a graphical user interface (GUI) that you can use to run the boundary scan system test. This command displays the SCET90: Boundary Scan Configuration window:

**SCET90: Boundary Scan Configuration**

**Configuration:**

Side/Port	Description
<input checked="" type="checkbox"/> A/ 0	CP02 00 @ B001 REV 3100
A/ 1	[ Not Used (A/ 1) ]
A/ 2	[ Not Used (A/ 2) ]
A/ 3	[ Not Used (A/ 3) ]
<input checked="" type="checkbox"/> A/ 4	CP02 01 @ B002 REV 3100
A/ 5	[ Not Used (A/ 5) ]
A/ 6	[ Not Used (A/ 6) ]
A/ 7	[ Not Used (A/ 7) ]
<input checked="" type="checkbox"/> A/ 8	CP02 02 @ B003 REV 3100
A/ 9	[ Not Used (A/ 9) ]
A/10	[ Not Used (A/10) ]
A/11	[ Not Used (A/11) ]
<input checked="" type="checkbox"/> A/12	CP02 03 @ B004 REV 3100
A/13	[ Not Used (A/13) ]
A/14	[ Not Used (A/14) ]
A/15	[ Not Used (A/15) ]
<input checked="" type="checkbox"/> A/16	SR01 00 @ C001 REV 1007
A/17	[ Not Used (A/17) ]
A/18	[ Not Used (A/18) ]
A/19	[ Not Used (A/19) ]
<input checked="" type="checkbox"/> A/20	CM02 00 @ C002 REV 2100
A/21	[ Not Used (A/21) ]
A/22	[ Not Used (A/22) ]
A/23	[ Not Used (A/23) ]
<input checked="" type="checkbox"/> A/24	CM02 01 @ C003 REV 2100
A/25	[ Not Used (A/25) ]
A/26	[ Not Used (A/26) ]
A/27	[ Not Used (A/27) ]
<input checked="" type="checkbox"/> A/28	CM02 02 @ C004 REV 2100
A/29	[ Not Used (A/29) ]
A/30	[ Not Used (A/30) ]
A/31	[ Not Used (A/31) ]

Sort By:

**Boundary Scan Port:** Side A/Port 4

**Module Type:**

**Module Location:**

**Module Revision:**

**Tests:**

**Directory:**

970225.142352/

970225.143546/

970225.144120/

7 files found

Perform the following procedure to run the boundary scan system test from this window:

1. In the scroll box on the left side of the window, select the modules that you want to test. A check mark (✓) next to an entry indicates that the module is selected. Click the ADJUST mouse button on an entry to select or deselect the entry.

When you click the SELECT mouse button on an entry, the window shows the Boundary Scan Port, Module Type, Module Number, and Module Revision data for the entry. You can modify the Module Type, Module Number, and Module Revision data.

**NOTE:** Use the Sort By settings ( and ) to change the order in which the scroll box displays the module information.

2. Click on Tests: , , , or  to specify the tests that you want to run.

Refer to the *Boundary Scan System Test* document, publication number HDM-117-B, for more information about the tests.

3. Choose **Run Selected Tests -> Physical Partition 0, Run Selected Tests -> Physical Partition 1, or Run Selected Tests -> Both Partitions** to run the tests.

When you run a test, SCE creates a new directory in the `usr/bscan` directory structure to store the configuration file and the results from the test. The directory name includes the mainframe serial number and the date and time that you ran the test.


4. View the results. Table 22 describes the buttons that you can use to view the results.

Table 22. Buttons That Display Boundary Scan Test Results


Button	Description
<input type="button" value="View Configuration..."/>	Displays the configuration file that SCE used to perform the selected tests
<input type="button" value="View Setup Results..."/>	Displays the results of a setup test
<input type="button" value="View ID Results..."/>	Displays the results of an ID test
<input type="button" value="View Shift Results..."/>	Displays the results of a shift test
<input type="button" value="View Scan Results..."/>	Displays the results of a scan test

You can view the results from a previous boundary scan system test by clicking on the directory name in the scroll box and then clicking on one of the buttons that Table 22 describes.

To delete the boundary scan test files that you no longer need, click on the directory name in the scroll box and then click on the


 button.

### Assume → Physical Partition 0




The Assume → Physical Partition 0 command, as shown at the left, sends the current configuration data for physical partition 0 to all clients without updating the sanity tree.

### Assume → Physical Partition 1




The Assume → Physical Partition 1 command, as shown at the left, sends the current configuration data for physical partition 1 to all clients without updating the sanity tree. This command is available only when SCE contains a configuration for a CRAY T932 mainframe with two physical partitions.

### Assume → Both Partitions



The Assume → Both Partitions command, as shown at the left, sends the current configuration data for both physical partitions to all clients without updating the sanity tree. This command is available only when SCE contains a configuration for a CRAY T932 mainframe with two physical partitions.

### Assert → Physical Partition 0



The Assert → Physical Partition 0 command, as shown at the left, generates a new sanity tree for physical partition 0 and sends the configuration data to all clients.

SCE performs the following functions in physical partition 0 to assert the configuration:

1. SCE opens the boundary scan channel, performs a soft master clear on the boundary scan channel, and closes the boundary scan channel.


2. SCE turns on the sanity code generator on the IO module and verifies that the generator is on by using the logic monitor of the IO module to check test points. Then, SCE resets the IO configuration codes.
3. SCE turns on the sanity code from the IO module to the shared module and verifies the sanity code by checking test points on the IO module.
4. SCE configures the shared module. The shared module does not have configuration test points, so verification is not possible.
5. SCE turns on the sanity codes from the shared module to each of the CP modules configured in the system and verifies the sanity codes by checking sanity test points on the shared module.
6. SCE configures the CP modules and verifies the configurations by checking test points. SCE configures memory as part of the CP module configuration process.
7. SCE configures the shared ports.
8. SCE turns on the sanity code from each CP module to the IO module and verifies the sanity code by checking test points on the IO module.
9. SCE configures the IO module and verifies the configuration by checking test points on the IO module.
10. SCE configures the LOSP, HISP, and VHISP channels and verifies the configurations by checking test points on the IO module.

**NOTE:** If SCE detects errors while attempting to verify a configuration, the window shown in Figure 4 appears. Click on **View Log** to view a log of the detected errors. Click on **Continue** to continue.



Figure 4. Configuration Verification Errors Detected



## Assert → Physical Partition 1




The Assert → Physical Partition 1 command, as shown at the left, generates a new sanity tree for physical partition 1 and sends the configuration data to all clients. This command is available only when SCE contains a configuration for a CRAY T932 mainframe with two physical partitions.

SCE performs the following functions in physical partition 1 to assert the configuration:

1. SCE opens the boundary scan channel, performs a soft master clear on the boundary scan channel, and closes the boundary scan channel.
2. SCE turns on the sanity code generator on the IO module and verifies that the generator is on by using the logic monitor of the IO module to check test points. Then, SCE resets the IO configuration codes.
3. SCE turns on the sanity code from the IO module to the shared module and verifies the sanity code by checking test points on the IO module.
4. SCE configures the shared module. The shared module does not have configuration test points, so verification is not possible.
5. SCE turns on the sanity codes from the shared module to each of the CP modules configured in the system and verifies the sanity codes by checking sanity test points on the shared module.
6. SCE configures the CP modules and verifies the configurations by checking test points. SCE configures memory as part of the CP module configuration process.
7. SCE configures the shared ports.
8. SCE turns on the sanity code from each CP module to the IO module and verifies the sanity code by checking test points on the IO module.
9. SCE configures the IO module and verifies the configuration by checking test points on the IO module.
10. SCE configures the LOSP, HISP, and VHISP channels and verifies the configurations by checking test points on the IO module.

**NOTE:** If SCE detects errors while attempting to verify a configuration, the window shown in Figure 4 on page 66 appears. Click on  to view a log of the detected errors. Click on  to continue.

## Assert → Both Partitions





The Assert → Both Partitions command, as shown at the left, generates a new sanity tree for each physical partition and sends the configuration data to all clients. This command is available only when SCE contains a configuration for a CRAY T932 mainframe with two physical partitions.

SCE performs the following functions in each physical partition to assert the configuration:

1. SCE opens the boundary scan channel, performs a soft master clear on the boundary scan channel, and closes the boundary scan channel.
2. SCE turns on the sanity code generator on the IO module and verifies that the generator is on by using the logic monitor of the IO module to check test points. Then, SCE resets the IO configuration codes.
3. SCE turns on the sanity code from the IO module to the shared module and verifies the sanity code by checking test points on the IO module.
4. SCE configures the shared module. The shared module does not have configuration test points, so verification is not possible.
5. SCE turns on the sanity codes from the shared module to each of the CP modules configured in the system and verifies the sanity codes by checking sanity test points on the shared module.
6. SCE configures the CP modules and verifies the configurations by checking test points. SCE configures memory as part of the CP module configuration process.
7. SCE configures the shared ports.
8. SCE turns on the sanity code from each CP module to the IO module and verifies the sanity code by checking test points on the IO module.
9. SCE configures the IO module and verifies the configuration by checking test points on the IO module.

10. SCE configures the LOSP, HISP, and VHISP channels and verifies the configurations by checking test points on the IO module.

**NOTE:** If SCE detects errors while attempting to verify a configuration, the window shown in Figure 4 on page 66 appears. Click on  to view a log of the detected errors. Click on  to continue.

### Reset → Maintenance Channel → Physical Partition 0



The Reset → Maintenance Channel → Physical Partition 0 command, as shown at the left, resets the maintenance channel for physical partition 0 by resetting the front-end interface (FEI) for the channel.

### Reset → Maintenance Channel → Physical Partition 1



The Reset → Maintenance Channel → Physical Partition 1 command, as shown at the left, resets the maintenance channel for physical partition 1 by resetting the FEI for the channel.

This command is available only when SCE contains a configuration for a CRAY T932 mainframe with two physical partitions.

### Reset → Error Logger Channel → Physical Partition 0

*This command is not implemented yet.*

### Reset → Error Logger Channel → Physical Partition 1

*This command is not implemented yet.*

### Reset → Boundary Scan Channel → Physical Partition 0



The Reset → Boundary Scan Channel → Physical Partition 0 command, as shown at the left, resets the boundary scan channel for physical partition 0 by resetting the FEI for the channel.

## Reset → Boundary Scan Channel → Physical Partition 1



The Reset → Boundary Scan Channel → Physical Partition 1 command, as shown at the left, resets the boundary scan channel for physical partition 1 by resetting the FEI for the channel.

This command is available only when SCE contains a configuration for a CRAY T932 mainframe with two physical partitions.







Figure 5. Menu Quick Reference