

Power, Cooling, and Control System

(CRAY T932™ System)

HTM-095-B

Cray Research Proprietary

Cray Research, Inc.

Record of Revision

REVISION	DESCRIPTION
----------	-------------

- | | |
|---|---|
| | November 1995. Original printing. |
| A | June 1996. This version incorporates the mechanical quadrant numbering system throughout the document so that the reference information herein corresponds with other hardware and control system documentation. This version also updates the control system illustrations and the illustration of the WACS switches menu. All other versions of this document are obsolete. |
| B | April 1997. This version incorporates the new MUX (MX02) board established with ECO/FCO 27216/3228. All other versions of this document are obsolete. |

Any shipment to a country outside of the United States requires a letter of assurance from Cray Research, Inc.
--

This document is the property of Cray Research, Inc. The use of this document is subject to specific license rights extended by Cray Research, Inc. to the owner or lessee of a Cray Research, Inc. computer system or other licensed party according to the terms and conditions of the license and for no other purpose.

Cray Research, Inc. Unpublished Proprietary Information — All Rights Reserved.

Autotasking, CF77, CRAY, CRAY-1, Cray Ada, CraySoft, CRAY Y-MP, CRInform, CRI/TurboKiva, HSX, LibSci, MPP Apprentice, SSD, SUPERCLUSTER, SUPERSERVER, UNICOS, and X-MPEA are federally registered trademarks and Because no workstation is an island, CCI, CCMT, CF90, CFT, CFT2, CFT77, ConCurrent Maintenance Tools, COS, CRAY-2, Cray Animation Theater, CRAY APP, CRAY C90, CRAY C90D, Cray C++ Compiling System, CrayDoc, CRAY EL, CRAY J90, CRAY J90se, Cray NQS, Cray/REELlibrarian, CRAY S-MP, CRAY SUPERSERVER 6400, CRAY T3D, CRAY T3E, CRAY T90, CrayTutor, CRAY X-MP, CRAY XMS, CS6400, CSIM, CVT, Delivering the power . . ., DGauss, Docview, EMDS, GigaRing, HEXAR, IOS, ND Series Network Disk Array, Network Queuing Environment, Network Queuing Tools, OLNET, RQS, SEGLDR, SMARTE, SUPERLINK, System Maintenance and Remote Testing Environment, Trusted UNICOS, UNICOS MAX, and UNICOS/mk are trademarks of Cray Research, Inc.

Requests for copies of Cray Research, Inc. publications should be directed to:

CRAY RESEARCH, INC.
Customer Service Logistics
1100 Lowater Road
P.O. Box 4000
Chippewa Falls, WI 54729-0078
USA

Comments about this publication should be directed to:

CRAY RESEARCH, INC.
Service Publications and Training
890 Industrial Blvd.
P.O. Box 4000

Chippewa Falls, WI 54729-0078
USA

POWER, COOLING, AND CONTROL SYSTEM

Overview	4
Power Distribution System	7
Components	7
Power Distribution	20
120-Vac Power Distribution	20
330-Vdc Power Distribution	23
Power Supply Connections	27
Power Distribution to the Modules	40
Cooling System	51
Components	51
Dielectric-coolant Flow Paths	54
Fill Flow Path	54
Normal Flow Path	56
Drain Flow Path	58
Control System	61
Components	61
Control System Configuration	72
Monitored Conditions and Limits	74
Control System MUX Board	80
Control System Processes	85
Power-up Process	85
Power-down Process	87
Mainframe Drain Process	88
Mainframe Fill Process	90
WACS Commands and Sequence of Events	92
WACS Fault Limits	92

Figures

Figure 1.	CRAY T932 Mainframe	5
Figure 2.	Mainframe Chassis Block Diagram	6
Figure 3.	330-Vdc Power Input Components, Side A Locations	9
Figure 4.	120-Vac Power Input Components, Locations	11
Figure 5.	Power Supply Rack Locations	12
Figure 6.	Power Supply Rack, 8-position	13
Figure 7.	Power Supply Rack, 20-position	14
Figure 8.	Power Supply Rack, 16-position	15
Figure 9.	Power Staging Assembly Locations	17
Figure 10.	Power Bus Component Locations	19
Figure 11.	120-Vac Power Input Box	21
Figure 12.	120-Vac Power Block Diagram	22
Figure 13.	330-Vdc Power Input Components, Side A	24
Figure 14.	330-Vdc Power Block Diagram	26
Figure 15.	Power Supply Harness Connections	28
Figure 16.	Power Supply Connections	29
Figure 17.	Clock Power Supply and Power Staging Assembly	32
Figure 18.	Power Staging Assembly	37
Figure 19.	Low-voltage DC (LVDC) Buses and Bias Boards	41
Figure 20.	Left CP and IO LVDC Bus	42
Figure 21.	Left CM and NW LVDC Bus	43
Figure 22.	Right CP and IO LVDC Bus	44
Figure 23.	Right CM and NW LVDC Bus	45
Figure 24.	IO Module Connections	46
Figure 25.	Right CP Module Connections	47
Figure 26.	Shared Module Connections	47
Figure 27.	Boundary Scan Module Connections	48
Figure 28.	Network Module Connections	48
Figure 29.	Right Common Memory Module Connections	49
Figure 30.	Cooling System Component Locations	53
Figure 31.	Dielectric-coolant Fill Flow Path	55
Figure 32.	Dielectric-coolant Normal Flow Path	57
Figure 33.	Dielectric-coolant Drain Flow Path	59
Figure 34.	Main PLC Component Locations	62
Figure 35.	Main PLC Assembly with Voltage-adjust Board	63
Figure 36.	Voltage-adjust Board, Main Components	64

Figures (continued)

Figure 37.	Control System Bulkhead Components, Main PLC Assembly	66
Figure 38.	Level Sensor Locations	68
Figure 39.	Voltage Sense Points	70
Figure 40.	Control System MUX Board Locations	71
Figure 41.	CRAY T932 Control System Configuration	73
Figure 42.	Control System MUX Board	81
Figure 43.	Connector Pin Layout	82
Figure 44.	Power-up Sequence of Events	86
Figure 45.	Power-down Sequence of Events	87
Figure 46.	Drain Sequence of Events	89
Figure 47.	Fill Sequence of Events	91
Figure 47.	WACS Switches Menu	93

Tables

Table 1.	CRAY T932 Mainframe Specifications	4
Table 2.	Input Power Distribution	25
Table 3.	Input Power Connection	30
Table 4.	Power-supply Control System Connection	31
Table 5.	Input Power Connection	33
Table 6.	Power-staging Bus Connection	34
Table 7.	Control System Connection	35
Table 8.	Clock Module Connection	36
Table 9.	Input Power Connection	38
Table 10.	Power Staging Bus Connection	39
Table 11.	Low-voltage DC (LVDC) Buses	40
Table 12.	Control Cable Connections	66
Table 13.	Monitored Conditions	74
Table 14.	TTL Input Module	76
Table 15.	12-Vdc Output Module	77
Table 16.	Clock Select Options	78
Table 17.	Analog Input Base Converter	78
Table 18.	Analog Input Voltage Expander, Channel Address .	79
Table 19.	Analog Input Voltage Expander, Address Label ...	79
Table 20.	MUX Board Components	83
Table 21.	Fault Limits, CRAY T932 System, Side A or Side B	94

Overview

The CRAY T932 power, cooling, and control systems are interrelated and interdependent. The power system provides power to the mainframe mechanical and logic components, while the cooling system removes the heat from the mainframe components that is generated during this power distribution. During this process, the power and cooling systems must be monitored by a control system that verifies that both the power system and cooling system are within the correct tolerances. This document provides information about each of these systems.

Refer to Table 1 for the CRAY T932 mainframe physical, power, cooling, and control system specifications. Refer to Figure 1 for an illustration of the CRAY T932 mainframe.

Table 1. CRAY T932 Mainframe Specifications

Characteristic	Specification
Dimensions: Height Width Depth	61.85 in. (1,570 mm) 92.20 in. (2,342 mm) 58.50 in. (1,486 mm)
Weight: Mainframe with dielectric coolant	16,600 lbs (7,528 kg)
Cooling requirement: Coolant Standard flow rate	Dielectric coolant (Fluorinert liquid) 180 gpm
Input power: To power supplies To control system components	12 inputs, 100 A, 330 Vdc each 2 inputs, 4 A, 120 Vac each





Figure 1. CRAY T932 Mainframe

The CRAY T932 mainframe consists of two sides (side A and side B) and contains a maximum of 32 central processors. This document describes how the subsystems within the mainframe function together. The descriptions throughout this document refer to quadrants, stacks, or specific locations in the mainframe. Refer to Figure 2 for a top-view block diagram of the locations in the mainframe chassis.





Figure 2. Mainframe Chassis Block Diagram

NOTE: It is often impractical to illustrate both sides of the mainframe in the same visual frame. Unless otherwise indicated in the text of this document, the reader should assume that the operations and characteristics described for one side of the mainframe mirror those on the opposite side.

Power Distribution System

The power distribution system consists of several components. The following subsections describe these components and their respective locations and functions in the CRAY T932 computer system.



Components

330-Vdc Power Input Components The CRAY T932 computer system receives 330-Vdc power from the two high-voltage DC devices (HVDCs) along twelve input lines (six lines from each HVDC-160). These twelve 330-Vdc circuits (six on each side) supply power to the mainframe power supplies and consist of the following components. Figure 3 illustrates the locations of the 330-Vdc power input components in side A of the mainframe. The configuration of these components in side B mirrors that of side A.

330-Vdc Terminal Blocks The thirty-six 330-Vdc terminal blocks (six plus, six minus, and six ground in each side) provide the grounded connections for the 330-Vdc power lines (L1 through L12). These twelve power lines provide power to the power supplies in the six power-supply rack assemblies (three in each side).

HVDC Filters The twelve HVDC filters (six in each side) prevent electrical noise from entering or leaving the mainframe. Each of the twelve incoming 330-Vdc power lines is filtered by an HVDC line filter located between the terminal blocks and the power supply racks.

HVDC Isolation Board The six HVDC isolation boards optically isolate the control system from the 330-Vdc power. Each HVDC isolation board connects to two incoming 330-Vdc power lines and reduces the voltage by a factor of 100 by sending the input signal through an opto-isolator. This opto-isolator converts the signal into light through an LED and then converts it back to an electrical signal through a photo detector. This process isolates the high-voltage input from the low-voltage output.

*Power Supply
Rack
Assemblies*

The six power-supply rack assemblies (three in each side of the mainframe) contain the mainframe power supplies, the master-clock box, and the three power-staging boxes. Each of the two 20-position power supply racks holds 20 power supplies and receives 330-Vdc power from HVDC lines 2, 3, and 4. Each of the two 16-position power supply racks holds 15 power supplies and a power staging box. These 16-position racks receive 330-Vdc power from HVDC lines 5 and 6. The 8-position power supply rack in side A holds 7 power supplies and the master-clock power box and receives 330-Vdc power from HVDC line 1. The 8-position power supply rack in side B holds 7 power supplies and a power staging assembly and receives power from HVDC line 1.

*Power Supply
Harness
Assemblies*

Each of the power-supply rack assemblies contains a harness assembly that distributes 330-Vdc, 100-A power from the output connections of the HVDC filters to the power supplies in the rack assemblies. These harness assemblies also contain the control signal wiring for the power supplies.

NOTE: Refer to the “Power Supplies” subsection, which begins on page 12, for detailed tables and illustrations of the power supply racks and harness connections. The “330-Vdc Power Distribution” subsection later in this document provides detailed information about the isolation boards, the HVDC filters, and the terminal blocks.




Figure 3. 330-Vdc Power Input Components, Side A Locations

120-Vac Power Input Components The CRAY T932 computer system receives 120-Vac power from the two high-voltage DC devices (HVDCs). Each of the two 120-Vac input circuits consists of three lines: a power line, a neutral line, and a ground line. These circuits supply power to the two mainframe programmable logic controllers (PLCs) and consist of the following components.

120-Vac Power Input Box One 120-Vac power input box contains the terminal blocks and the main circuit breaker for 120-Vac power distribution to the entire CRAY T932 mainframe. The box mounts to the chassis in the clock-module end of the mainframe.

120-Vac Terminal Blocks The 120-Vac terminal blocks provide the grounded connections for the two 120-Vac power input lines to the mainframe (one from each HVDC). Wires from the power-line terminal blocks attach to the main circuit breaker and then to the two drop cord receptacles at the bottom of the 120-Vac power input box. Wires from neutral and ground terminal blocks attach directly to the two drop cord receptacles.

Main Circuit Breaker The main circuit breaker in the power input box connects to the two 120-Vac power lines that come from the 120-Vac terminal blocks. The circuit breaker provides protection for the computer equipment for currents that exceed 4 amps. This circuit breaker also provides the main power disconnect for the mainframe. When this circuit breaker is tripped (or turned off), 120-Vac power is disconnected. Without the 120-Vac power, the control system powers down, which disables the high-voltage DC (HVDC) devices and the low-voltage DC (LVDC) buses.

120-Vac Drop Cords The two 120-Vac drop cords supply power to the two programmable logic controllers (PLCs) from the two 120-Vac output circuits in the power input box. Each 3-wire drop cord contains a plug on each end to provide power, neutral, and ground continuity between a receptacle on the 120-Vac power input box and a corresponding receptacle in one of the PLC rack assemblies.

PLC Circuit Breakers Each of the PLC racks (main and standby) contains a 120-Vac circuit breaker that receives power from the receptacle attached to the corresponding drop cord plug. When this circuit breaker is tripped (or turned off), 120-Vac power is disconnected from the PLC rack, which allows service or replacement of the PLC components.

Figure 4 illustrates the locations of these components in the clock-module end of the mainframe. Side B contains one of the drop cord receptacles and a 120-Vac circuit breaker in the standby PLC.




Figure 4. 120-Vac Power Input Components, Locations

Power Supplies

The power supplies convert the 330-Vdc power to logic-level voltages, which are routed to the modules. The power supplies are mounted in the six power supply racks (three in side A and three in side B) and are cooled by dielectric coolant. All of the mainframe power supplies are immersed in dielectric coolant.

Figure 5 illustrates the three power supply racks and their locations in side A. Side B contains the other three power supply racks in a mirrored configuration. The following subsection provides detailed information about the mainframe power supplies in these power supply racks.





Figure 5. Power Supply Rack Locations

The power supplies are used in parallel and configured in an N+1 configuration, which enables the power supplies to share the current load. This configuration provides one more power supply on each of the power bus levels than is required to drive the load. If one of the power supplies on any bus line fails, the other power supplies pick up the load of the failed power supply until the failed power supply is replaced. These extra power supplies provide increased power reliability for the computer system.

Figure 6 illustrates the power supply configuration of the 8-position power supply rack in side A of the mainframe. The configuration of the 8-position power supply rack in side B mirrors this configuration, except that slot 8 in side B contains a power staging assembly, but it does not contain a clock power supply.




Slot Number	Voltage	Function
1, 2, 3, 4	-2.7 Vdc	Provides power to the shared (SR) module, common memory (CM) modules, and network (NW) modules in quadrant 1
5, 6, 7	-3.5 Vdc	Provides power to the SR module, CM modules, and NW modules in quadrant 1
8	-5.2 Vdc	Provides power to the clock module †

† Power supply slot number 8 also contains the power staging board for quadrant 1.

Figure 6. Power Supply Rack, 8-position

Figure 7 illustrates the configuration of a 20-position power supply rack.



Slot Number	Voltage	Function
9, 10, 11, 14, 15, 16, 20	-2.7 Vdc	Provides power to the input/output (IO) and central processor (CP) modules in quadrant 1
12, 13, 17, 18	-2.7 Vdc	Provides power to the IO and CP modules in quadrant 2, bused with power supplies in slots 29 and 30
19, 24, 25	-5.2 Vdc	Provides power to the CM modules in quadrant 1
21, 22, 26, 27	-3.5 Vdc	Provides power to the CP and IO modules in quadrant 1
23, 28	-3.5 Vdc	Provides power to the CP and IO modules in quadrant 2, bused with power supplies in slots 37 and 41

Figure 7. Power Supply Rack, 20-position

Figure 8 illustrates the power supply configuration of a 16-position power supply rack.



Slot Number	Voltage	Function
29, 30	-2.7 Vdc	Provides power to the IO and CP modules in quadrant 2, bused with power supplies in slots 12, 13, 17, and 18
31, 32, 34, 35, 36	-2.7 Vdc	Provides power to the boundary scan (BS), CM, and NW modules in quadrant 2
33	N/A	Contains the power staging box
37, 41	-3.5 Vdc	Provides power to the IO and CP modules in quadrant 2, bused with power supplies in slots 23 and 28
38, 39, 40	-3.5 Vdc	Provides power to the BS, CM, and NW modules in quadrant 2
42, 43, 44	-5.2 Vdc	Provides power to the CM modules in quadrant 2

Figure 8. Power Supply Rack, 16-position

*Clock Power
Supply and
Power Staging
Assemblies*

The clock power supply is a -5.2-Vdc power supply that operates in slot number 8 in side A of the mainframe. Although it looks like a regular power supply, the clock power supply contains both a master-clock power board and a power staging assembly. This combination of components allows the clock power supply to perform several functions. The master-clock power board receives 330-Vdc power from both HVDCs and distributes it to the optical clock module. The power staging assembly performs circuit-check and power staging functions in mainframe quadrant 1.

In addition to the power staging assembly in the clock power supply in side A, the mainframe contains three more power staging assemblies: one in slot number 33 in each of the two 16-position power supply racks and one in slot 8 in side B. These four power staging assemblies are used during the initial power-up of the mainframe. When the mainframe powers up, each power staging assembly sends a small voltage across the LVDC power buses in that particular module quadrant to check for any short circuits within the LVDC buses. If no short circuits exist, the control system sequentially enables the power supplies.

Figure 9 illustrates the locations of the clock power supply and the power staging assemblies in side A of the mainframe. Side B of the mainframe contains the other two power staging assemblies: one in slot number 8 and one in slot number 33. The following subsections of this document contain detailed information about these components.




Figure 9. Power Staging Assembly Locations

Refer to Figure 10 for the locations of the following components, which are attached to one of the eight LVDC buses in the mainframe. The “Power Distribution to the Modules” subsection, which begins on page 40, describes these power distribution components in detail.

Power Bus Connections

The power bus connections on the LVDC power buses attach to the power supply bus connections and route power from the power supplies to the appropriate layers in the LVDC power buses.

LVDC Power Buses

The LVDC power buses route the power from the power supplies to the appropriate modules.

Bus Interface Assembly

Each module has a bus interface assembly attached to it. This interface assembly mounts on the power bus, and a bus strap connects the bus interface assembly to the module voltage regulator.

Module Assembly

Each module assembly consists of a module logic board and a voltage regulator that regulates the noise caused by dynamic module loads. When a module assembly requires replacement, both the module logic board and the voltage regulator require replacement.





Figure 10. Power Bus Component Locations

Power Distribution

The CRAY T932 mainframe receives two types of electrical power from the two HVDCs: 120-Vac power and 330-Vdc power. The input power to the mainframe consists of six 330-Vdc power lines from each HVDC (12 total) and one 120-Vac power line from each HVDC (2 total). You must disconnect the 14 power sources before you service the mainframe.



The “Components” subsection of this document provides a general overview of the power distribution components. The following subsections describe the two types of power and the power distribution components in more detail.

120-Vac Power Distribution

The 120-Vac power powers the programmable logic controllers (PLCs). Two single-phase, 120-Vac power lines (one from each HVDC) enter the mainframe at the power input box and attach to terminal blocks. Each 120-Vac input line contains three wires: the power line, the neutral line, and the ground line. The ground lines connect to ground lugs in the input box. The power lines connect to the main circuit breaker, and the neutral lines connect to the neutral line in the two 120-Vac drop cords. Figure 11 illustrates the components of the 120-Vac power input box.




Figure 11. 120-Vac Power Input Box

The two drop cords attach to compatible receptacles in the two PLC racks and provide 120-Vac power to the PLC power supplies. Each 120-Vac power line attaches to a circuit breaker in the control system bulkhead in each controller assembly. When the circuit breaker is turned off, it isolates the PLC rack assembly from 120-Vac power, which allows service or replacement of the PLC components.

The 120-Vac power lines also provide power to a 12-Vdc power supply in each PLC rack assembly. Each of the two 12-Vdc power supplies mounts to a bracket in the floor plate behind the control system bulkhead. These power supplies provide power to the 12-Vdc output modules in the PLC racks and to the control system multiplexer (MUX) boards. The “Control System” section later in this document describes the PLC and MUX components in detail. Refer to Figure 12 for a block diagram of the 120-Vac power circuits.





Figure 12. 120-Vac Power Block Diagram

330-Vdc Power Distribution

The six 330-Vdc input power lines from each of the high-voltage DC devices (HVDCs) connect to power circuit line connections in the CRAY T932 mainframe. Each 330-Vdc connection has three lines: plus, minus, and ground. The plus and minus lines connect to EMI line filters, which prevent any electrical noise from entering or leaving the mainframe. Each ground line of the 330-Vdc lines connects to a separate ground terminal, which provides ground through the chassis at the terminal blocks.

The power circuit line connections contain high voltage when the two HVDCs are running and supplying power to the mainframe. When either of the two HVDCs is supplying 330-Vdc power to the mainframe, do not disconnect the 330-Vdc connections or attempt to service the mainframe.



The control system also monitors the 330-Vdc power to the power supplies. At each of the twelve HVDC filter locations, a wire connects to a lug connection and then to one of the six HVDC isolation boards. The isolation boards reduce the voltage by a factor of 100 and then send the reduced voltage to the analog input base converters in the control system.

Figure 13 illustrates the 330-Vdc terminal blocks, HVDC filters, and isolation boards, which are located in the main controller enclosure in side A. Side B contains the same quantity of 330-Vdc power input components as side A, but side B connects to a separate HVDC. Refer to the *Field Replacement Procedures* document, CRI publication number HMM-111-0, before you handle or replace any of these components.




Figure 13. 330-Vdc Power Input Components, Side A

Six screws attach each HVDC filter to the enclosure panel and provide the filter ground connections. The plus and minus input connections on the front of the HVDC filters (F1 through F6 and F7 through F12) attach to the plus and minus power circuit lines (L1 through L6 and L7 through L12). The HVDC filter output connections in the I/O bulkheads supply 330-Vdc power to the power supply harnesses. Each power supply harness distributes 330-Vdc power to specific power supplies in the power-supply rack assemblies. Table 2 provides information about the 330-Vdc input power distribution.

Table 2. Input Power Distribution

Input Line	HVDC Filter	Isolation Board	Side	Power Supply Locations
L1	F1	Iso 1	Side A	1 – 8
L2	F2	Iso 1	Side A	9, 14, 19, 24, 25, 26
L3	F3	Iso 2	Side A	10, 11, 15, 16, 20, 21, 22, 27
L4	F4	Iso 2	Side A	12, 13, 17, 18, 23, 28
L5	F5	Iso 3	Side A	29, 30, 31, 32, 36, 37, 41, 44
L6	F6	Iso 3	Side A	33, 34, 35, 38, 39, 40, 42, 43
L7	F7	Iso 4	Side B	1 – 8
L8	F8	Iso 4	Side B	9, 14, 19, 24, 25, 26
L9	F9	Iso 5	Side B	10, 11, 15, 16, 20, 21, 22, 27
L10	F10	Iso 5	Side B	12, 13, 17, 18, 23, 28
L11	F11	Iso 6	Side B	29, 30, 31, 32, 36, 37, 41, 44
L12	F12	Iso 6	Side B	33, 34, 35, 38, 39, 40, 42, 43

Figure 14 provides a block diagram of the 330-Vdc input power distribution. The blocks in Figure 14 represent the components in the mainframe, but they do not represent the physical shapes or locations of those components.





Figure 14. 330-Vdc Power Block Diagram

Power Supply Connections

The power supplies mount in the six power supply racks (three racks in each side of the mainframe) and route power through the power bus connections to the low-voltage DC (LVDC) module power buses. With the exception of the clock power supplies and power staging assemblies, each power supply has the same appearance, with a slight variation of the keying block. (The keying block prevents a power supply from being inserted into the wrong slot in the power supply rack.)

The regular power supplies and the clock power supplies use blind-mate connections, which are located on the back of the power supply. However, the regular power supplies and the clock power supplies have different connection configurations. Refer to Figure 15 for an illustration of the power-supply harness connections for both types of power supplies.

NOTE: Each type of mainframe power supply and power staging assembly is a field replaceable unit (FRU); therefore, no field repair is recommended. The following connector descriptions and power supply illustrations provide information intended to help the reader understand the theory of operation of the power system. Refer to the *Field Replacement Procedures*, Cray Research publication number HMM-111-0, before you handle any of the power supply components.






Figure 15. Power Supply Harness Connections

The regular power supplies have three connections: the input power connection, the control system connection, and the power-supply bus connection. Refer to Figure 16 for an illustration of the power supply connections and keying block positions.

The power-supply bus connection is a multicontact connection. This connection transfers the output current from the power supply to the power bus at every contact point. Figure 16 illustrates this connector.




Figure 16. Power Supply Connections

The input power connection on the regular power supplies is an 8-slot blind-mate connector. Table 3 describes the function of each connector position in this connector.

Table 3. Input Power Connection

J2 Connector Position	Function
1	Plus 330-Vdc input
2	Plus 330-Vdc input
3	Not used
4	Ground
5	Minus 330-Vdc input
6	Minus 330-Vdc input
7	Not used
8	Ground

The control system connection is a 24-slot, blind-mate connector. The only power supply condition that the control system monitors is the “power supply good” condition. If any other power-supply fault conditions occur, the “power supply good” condition sends a signal to the control system to indicate that the power supply has failed and requires replacement. Table 4 provides the pin numbers and the signal names for this connector.

Table 4. Power-supply Control System Connection

J1 Pin Number †	Signal Name
1	Remote enable
2	Common return
3	Plus voltage remote sense
4	Minus voltage remote sense
5	Current share
6	Current share return
7	Clock
8	Clock return
9	ISO +5V to 15V
10	ISO return (flag return)
11	Power supply good
12	Input power good
13	Overtemperature flag
14	Overvoltage flag
15	Not used
16	Analog margin enable
17	Low margin enable (-5 %)
18	High margin enable (+5 %)
19	Margin return
20	Analog margin input
21	Not used
22	Current monitor return
23	Current monitor
24	Local current share

† Only the pin numbers that are **bold** carry signals that are wired into the power supply harness.

The clock power supply in power-supply slot number 8 in side A of the mainframe contains a master-clock power board, a power staging board, and four external connections: an input power connection, a power-staging bus connection, a control system connection, and a clock module connection. Refer to Figure 17 for an illustration of this field-replaceable assembly and its connections.





Figure 17. Clock Power Supply and Power Staging Assembly

The input power connection on the clock power supply is an 8-pin connector that receives 330-Vdc power from the HVDC and distributes it to the input connectors on the master-clock power board and on the power staging board. Table 5 provides the pin numbers and the signal names for this connector.

Table 5. Input Power Connection

J2 Pin Number	Board Connector-Pin Number	Signal Name
1	P1-1	HVDC 1 (+)
2	P7-1	HVDC 2 (+)
3	P8-1	HVDC 3 (+)
4	Ring terminal	Chassis GND
5	P1-3	HVDC 1 (-)
6	P7-6	HVDC 2 (-)
7	P8-3	HVDC 3 (-)
8	Ring terminal	Chassis GND

Each regular power supply and each of the three self-contained power staging assemblies receives 330-Vdc power from one of two HVDCs. However, the clock power supply in slot number 8 in side A of the mainframe receives 330-Vdc power from both HVDCs. You must, therefore, disconnect the 330-Vdc input power from both HVDCs before you handle the clock power supply.

	WARNING
	<p>Electrical Hazard. Turn off the 330-Vdc circuit breakers in both HVDCs to ensure that the power sources to both side A and side B are disconnected before you handle the clock power supply. Failure to do so could result in severe shock, burns, or death.</p>

The power-staging bus connection on the clock power supply is a 12-pin connector that connects the power staging assembly to the power bus. This connection is the output connection that allows the power staging assembly to send a small current across the LVDC buses in that particular quadrant to check for electrical shorts. Table 6 provides the pin numbers and the signal names for this connector.

Table 6. Power-staging Bus Connection

J4 Pin Number	Board Connector-Pin Number	Signal Name
1	P6-6	Short check -5.2 V CM1
2	P6-7	Short check -3.5 V CM1
3	P6-8	Short check -2.7 V CM1
4	P6-9	Short check -3.5 V CP1
5	P6-10	Short check -2.7 V CP1
6	Not used	Not used
7	P6-1	Short check +5.2 V (GND) CM1
8	P6-2	Short check +3.5 V (GND) CM1
9	P6-3	Short check +2.7 V (GND) CM1
10	P6-4	Short check +3.5 V (GND) CP1
11	P6-5	Short check +2.7 V (GND) CP1
12	Not used	Not used

The control system connection on the clock power supply is a 24-pin connector that routes information to and from the control system. Table 7 provides the pin numbers and signal names for this connector.

Table 7. Control System Connection

J1 Pin Number	Board Connector- Pin Number	Signal Name
1	P2-8	Enable clock main
2	P3-7	Enable clock standby
3	P2-1	Laser select main
4	P3-1	Laser select standby
5	P2-4	Clock select 0 main
6	P3-4	Clock select 0 standby
7	P2-5	Clock select 1 main
8	P3-5	Clock select 1 standby
9	P2-6	Clock select 2 main
10	P3-6	Clock select 2 standby
11	P2-2	Laser alarm 1
12	P2-3	Laser alarm 2
13	P2-7	Power good clock
14	P2-11	Margin enable clock
15	P2-9	Margin signal clock
16	P2-10	Margin signal return
17	P3-8	Return
18	P2-12	Return
19	P2-13	- Sense -5.2 V
20	P2-14	+ Sense -5.2 V
21	P5-3	Short check enable -2.7 V Q1
22	P5-2	Short check enable -3.5 V Q1
23	P5-1	Short check enable -2.7 V Q1
24	P5-4	Return

The clock module connection is also a 24-pin connector; it routes control information to the clock module. Table 8 provides the pin numbers and signal names for this connector.

Table 8. Clock Module Connection

J3 Pin Number	Board Connector- Pin Number	Signal Name
1	P4-1	Laser 1 enable
2	P4-2	Laser 1 return
3	P4-3	Laser 2 enable
4	P4-4	Laser 2 return
5	P4-5	Laser 1 alarm
6	P4-6	Laser 1 alarm return
7	P4-7	Laser 2 alarm
8	P4-8	Laser 2 alarm return
9	P4-10	Clock select 0 complement
10	P4-9	Clock select 0 true
11	P4-12	Clock select 1 complement
12	P4-11	Clock select 1 true
13	P4-14	Clock select 2 complement
14	P4-13	Clock select 2 true
15	P4-15	Enable slow
16	P4-18	Enable normal 1
17	P4-17	Enable normal 2
18	P4-16	Enable fast
19	P4-24	- Sense
20	P4-25	+ Sense
21	P4-23	-5.2 V
22	P4-26	-5.2 V return
23	P4-21	-5.2 V
24	P4-22	-5.2 V return

In addition to the power staging assembly in the master-clock box, the mainframe contains three other power staging assemblies: one in slot number 8 in side A and one in slot number 33 in each side of the mainframe. Each of these three assemblies contains a power staging board and two external connections: an input power connection and a power-staging bus connection. Like the clock power supply and regular power supplies, the power staging assembly is a field replaceable unit. Refer to Figure 18 for an illustration of this assembly and its connections.




Figure 18. Power Staging Assembly

The input power connection on the power staging assembly is an 8-pin connector that receives 330-Vdc power from the HVDC and distributes it to the input connector on the power staging board. Table 9 provides the pin numbers and the signal names for this connector.

Table 9. Input Power Connection

J2 Pin Number	Board Connector- Pin Number	Signal Name
1, 3, 5, 7	Not used	Not used
2	P7-1	HVDC 1 (+)
4	Ring terminal	Chassis GND
6	P7-6	HVDC 1 (-)
8	Ring terminal	Chassis GND

The power-staging bus connection on the power staging assembly is a 24-pin connector that connects the power staging assembly to the power bus. This connection is the output connection that allows the power staging assembly to send a small current across the LVDC buses in that particular quadrant to check for electrical shorts. Table 6 provides the pin numbers and the signal names for this connector.

Table 10. Power Staging Bus Connection

J1 Pin Number	Board Connector-Pin Number	Signal Name
1	P6-6	Short check -5.2 V CM2
2	P6-7	Short check -3.5 V CM2
3	P6-8	Short check -2.7 V CM2
4	P6-9	Short check -3.5 V CP2
5	P6-10	Short check -2.7 V CP2
6, 7, 8, 9, 10	Not used	Not used
11	P5-3	Short check enable -2.7 V Q2
12	P5-2	Short check enable -3.5 V Q2
13	P6-1	Short check +5.2 V (GND) CM2
14	P6-2	Short check +3.5 V (GND) CM2
15	P6-3	Short check +2.7 V (GND) CP2
16	P6-4	Short check +3.5 V (GND) CP2
17	P6-5	Short check +2.7 V (GND) CP2
18, 19, 20, 21, 22	Not used	Not used
23	P5-1	Short check enable -5.2 V Q2
24	P5-4	Return

Power Distribution to the Modules

After the power supplies convert the 330-Vdc power to specific voltages, the eight low-voltage DC (LVDC) buses distribute the voltage to the appropriate modules in the mainframe. Each of the eight LVDC buses consists of up to ten laminated layers of copper; each layer distributes a specific voltage to designated module and sense point locations. Table 11 provides information about the specific voltages and locations of the eight LVDC buses.

Table 11. Low-voltage DC (LVDC) Buses

LVDC Bus	Quadrant	Module Sections	Voltages	Modules
CP and IO Left	Q1 Side A	E and F	-2.7 V, 2.7-V Gnd, -3.5 V, 3.5-V Gnd	IO module in Location E and CP modules in Stack F
CM and NW Left	Q1 Side A	G and H	-2.7 V, 2.7-V Gnd, -3.5 V, 3.5-V Gnd, -5.2 V, 5.2-V Gnd	SR and NW modules in Location G and CM modules in Stack H
CP and IO Right	Q2 Side A	I and J	-2.7 V, 2.7-V Gnd, -3.5 V, 3.5-V Gnd	IO module in Location I and CP Modules in Stack J
CM and NW Right	Q2 Side A	K and L	-2.7 V, 2.7-V Gnd, -3.5 V, 3.5-V Gnd, -5.2 V, 5.2-V Gnd	BS and NW modules in Location K and CM modules in Stack L
CP and IO Left	Q1 Side B	M and N	-2.7 V, 2.7-V Gnd, -3.5 V, 3.5-V Gnd	IO module in Location M and CP modules in Stack N
CM and NW Left	Q1 Side B	O and P	-2.7 V, 2.7-V Gnd, -3.5 V, 3.5-V Gnd, -5.2 V, 5.2-V Gnd	NW modules in Location O and CM Modules in Stack P
CP and IO Right	Q2 Side B	A and B	-2.7 V, 2.7-V Gnd, -3.5 V, 3.5-V Gnd	IO module in Location A and CP modules in Stack B
CM and NW Right	Q2 Side B	C and D	-2.7 V, 2.7-V Gnd, -3.5 V, 3.5-V Gnd, -5.2 V, 5.2-V Gnd	BS, SR, and NW modules in Location C and CM modules in Stack D

Two bias boards mount in the door of each 8-position power supply rack. Each of the four bias boards receives -2.7 Vdc from the LVDC buses on its side of the mainframe and supplies a low-voltage bias (-1.2 Vdc) to the LVDC buses on the other side. Because the modules in one side of the mainframe share logic with the modules in the other side through the system interconnect board (SIB), each side must maintain circuit signal integrity while powered up and protect its module circuits while powered down. The four bias boards maintain a minimum of -1.2 Vdc on the

LVDC buses so that, when one side of the mainframe powers down, the driver circuits in the modules in the powered-up side do not damage the receiver circuits in the modules in the powered-down side.

Figure 19 illustrates the locations of the eight LVDC buses and the four bias boards in the mainframe. Refer to Cray Research Engineering specification number 35335100 for detailed information about the bias boards.




Figure 19. Low-voltage DC (LVDC) Buses and Bias Boards

Because the chassis area near the LVDC buses contains other wiring and module hardware, it is difficult to distinguish each bus after it is installed in the mainframe tank assembly. Refer to Figure 20 through Figure 23 for individual illustrations of the four types of LVDC buses.




Figure 20. Left CP and IO LVDC Bus




Figure 21. Left CM and NW LVDC Bus




Figure 22. Right CP and IO LVDC Bus




Figure 23. Right CM and NW LVDC Bus

The LVDC buses distribute power to the modules. A bus interface assembly mounts on each LVDC bus and routes the power through metal bus straps to the module voltage regulator. Each voltage regulator, in turn, provides a steady voltage to the module power pads and protects the module from any voltage fluctuations or voltage spikes.

Each module type contains a different voltage regulator, bus interface assembly, and bus strap configuration for power distribution. Refer to Figure 24 through Figure 29 for illustrations of each type of module connection.

NOTE: Some module types have a right-hand and a left-hand orientation in the mainframe, but this section illustrates only one orientation for each module type. Modules in some systems might contain different quantities of bus straps than the modules shown in this section.




Figure 24. IO Module Connections




Figure 25. Right CP Module Connections




Figure 26. Shared Module Connections




Figure 27. Boundary Scan Module Connections




Figure 28. Network Module Connections




Figure 29. Right Common Memory Module Connections

This page intentionally left blank.

Cooling System


The cooling system removes heat generated by the modules and power supplies and transfers it to the two heat exchanger units (HEU-T90s). The modules and power supplies are submersed in dielectric coolant, which absorbs the heat generated by these modules and power supplies. The following subsections describe the components used within the mainframe.

Components

The cooling system in the CRAY T932 mainframe requires very few components, which the following subsections describe. Refer to Figure 30 for an illustration of these component locations.

Dielectric Coolant

Dielectric coolants, such as Fluorinert liquid, are nonconductive liquids that absorb heat and transfer it away from the heat source. These liquids are inert and noncorrosive. Dielectric coolants are safe products when handled with care. Refer to the manufacturer’s Material Safety Data Sheet and the *Safe Use and Handling of Fluorinert Liquids* manual, Cray Research publication number HR-00306, for more information about Fluorinert liquid safety.



Supply Line

Each of the two HEU-T90s configured with a CRAY T932 computer system has a supply line that allows the flow of dielectric coolant from the heat exchanger to one side of the mainframe chassis.

Return Line

Each HEU-T90 has a return line that connects to one side of the mainframe chassis. These return lines route the dielectric coolant that has flowed through the mainframe and absorbed heat to the HEU-T90s, where the dielectric coolant is again cooled for reuse.

NOTE: If any service to the computer system components results in replenishment of the dielectric coolant, you must replenish the cooling system with Fluorinert liquid.

CAUTION

Replenish the cooling system with 3M Fluorinert electronic liquid only. Failure to do so could result in cooling system contamination and computer system failure.

Vent/Charge Line and Mainframe Stand Pipe

Each of the two HEU-T90s has a vent/charge line that connects to one side of the mainframe. These lines provide exchange routes for air to travel during the filling and draining of each side of the mainframe. During the fill process, the change in air pressure forces any air that may be in the mainframe chassis through the vent/charge line back to the reservoir in the corresponding HEU-T90. Likewise, during the drain process, the change in air pressure forces the air in the HEU-T90 reservoir through the vent/charge line and through the stand pipe to the mainframe chassis.

Refer to Figure 30 for an illustration of these component locations on one side of mainframe. The component locations on the other side of the mainframe are the same in a mirrored configuration.




Figure 30. Cooling System Component Locations

Dielectric-coolant Flow Paths

The dielectric-coolant flow paths through the CRAY T932 mainframe are relatively simple. The following subsections describe the flow paths for the fill process, normal operation, and the drain process.

Fill Flow Path

During the mainframe power-up sequence, dielectric coolant flows into the mainframe through the supply lines. A pump in the corresponding HEU-T90 forces the dielectric coolant through the supply line into the bottom of that side of the mainframe tank. Cutouts in each side of the tank allow dielectric coolant to flow freely from the I/O section to the power supply sections and module sections. A valve in the corresponding HEU-T90 closes to prevent dielectric-coolant flow through the return line to the HEU during the fill process.

A tank divider isolates the two module quadrants in side A of the mainframe from the two module quadrants in side B of the mainframe. During the fill process, each side of the mainframe fills separately with coolant supplied by a separate HEU-T90.

As the dielectric coolant flows into the mainframe, any air that is displaced with dielectric coolant flows through the vent/charge line back to the corresponding HEU-T90 reservoir.

Figure 31 illustrates the fill flow path in one side of the mainframe. The fill flow path for both sides is the same.




Figure 31. Dielectric-coolant Fill Flow Path

Normal Flow Path

Dielectric coolant flows through the mainframe during normal operation in much the same way as during the fill process, except that instead of only filling the mainframe, the dielectric coolant constantly circulates through the supply line, the mainframe, and the return line to the HEU. While either side of the mainframe is powered up, dielectric coolant flows through that side at approximately 180 gpm. Figure 32 illustrates the normal flow path in one side of the mainframe. The normal flow path for both sides is the same.




Figure 32. Dielectric-coolant Normal Flow Path

Drain Flow Path

When either side of the mainframe is powered down, the dielectric coolant can be completely drained from that side or just partially drained, depending on what type of maintenance needs to be performed. If a module needs to be replaced, the side can be partially drained. If access to a power supply or to a component at a lower level is required, the entire side of the mainframe must be drained.

During the drain process for either side of the mainframe, the dielectric coolant drains through the return line, which is located near the bottom of the 16-position power supply section. The pump in the HEU-T90 suctions the dielectric coolant from that side of the mainframe, through the return line, and back to the HEU reservoir. Cutouts in the wall sections of the chassis allow the dielectric coolant level to remain at a relative equilibrium throughout that side during the drain process.

As the dielectric coolant drains from the mainframe to the HEU-T90, any air that is displaced by dielectric coolant in the HEU-T90 reservoir flows through the vent/charge line back to the mainframe.

Figure 33 illustrates the drain flow process for one side of the mainframe. The drain flow path for both sides is the same.




Figure 33. Dielectric-coolant Drain Flow Path

This page intentionally left blank.

Control System

The control system for the CRAY T932 mainframe monitors the power bus voltages, power supply current, and the dielectric-coolant level.

This subsection provides control-system information for the CRAY T932 mainframe only; it does not provide information about the entire control system. Refer to the *Control System Overview*, Cray Research publication number HTM-065-0, for detailed information about the control system. Refer to the *Power, Cooling, and Control System Troubleshooting Guide*, Cray Research publication number HTM-179-0, for detailed information about control system troubleshooting.

Components

Refer to Figure 34 for an illustration of the locations of the following mainframe control system components.

Programmable Logic Controllers (PLCs)

The two PLC racks (main and standby) are located on opposite sides of the CRAY T932 mainframe. These two controller assemblies are similar, but the main PLC in side A contains two components that the standby PLC in side B does not contain: the voltage-adjust board used for nominal-voltage adjustments and the analog output board used for power supply margining. A local area network (LAN) cable connects the two PLC racks and allows the two controllers to share monitored information. If one PLC fails, this sharing of information enables the other PLC to control the computer system until the failed PLC returns to operation.

Control System Bulkhead

Each controller (main and standby) contains an control system bulkhead that contains the 120-Vac input connection, the 120-Vac circuit breaker, and numerous control cable receptacles. The components in the control system bulkhead are described in detail later in this section.

Air Vents

Each of the two PLC rack enclosures contains five honeycomb air-vent panels. These ten panels allow pressurized underfloor air to enter the two controller compartments to cool the PLC components. These panels also serve as electronic filters, which prevent unacceptable electronic noises from exiting the controller enclosures.

Air Filters

A panel that is located below each of the two PLC rack enclosures contains a replaceable air filter. These two air filters prevent airborne contaminants from entering and exiting the two controller enclosures along with the pressurized underfloor air. These filters are installed during system installation and should be periodically replaced.




Figure 34. Main PLC Component Locations

Voltage-adjust Board

The voltage-adjust board attaches to the front of the main PLC and contains numerous electromechanical components including 20 potentiometers and 4 switches. The 20 potentiometers provide a means to manually adjust the power-supply output to each LVDC bus. The 4 switches provide a means to manually control the stop, start, circulate, and drain processes in the mainframe.

Figure 35 illustrates the main PLC assembly with the voltage-adjust board. Figure 36 provides a detailed illustration of the main components in the voltage-adjust board.





Figure 35. Main PLC Assembly with Voltage-adjust Board



Device	Device Type	Function
R2 – R40 †	Potentiometer	Regulates nominal power-supply voltage output
K1 – K5	Relay	Relays margins from support system to power supplies
SW1	Switch	Manual start switch
SW2	Switch	Manual stop switch
SW3	Switch	Manual circulate switch
SW4	Switch	Manual drain switch
J1	64-pin Connector	Receives margin signals from analog output module
J2	64-pin Connector	Sends analog margin signals to the power supplies
J3	12-pin Connector	Margin enable output to power supplies
J4	16-pin Connector	Margin enable input from controller, power input from main controller, and switch signal output to controller
J5	6-pin Connector	12-Vdc input power from standby controller

† The 20 even-numbered devices from R2 to R40 represent potentiometers.

Figure 36. Voltage-adjust Board, Main Components

<i>Control System Bulkhead Components</i>	Each PLC assembly (main and standby) contains a control system bulkhead that contains several interconnection components. These components, which are described below, provide the power connections to the controllers and the cabling interconnections between the control system, the mainframe, and other computer system devices. Figure 37 illustrates the control system bulkhead components in the main PLC assembly. The standby PLC assembly contains the same components.
<i>120-Vac Power Receptacle</i>	The 120-Vac power receptacle (J9) in each control system bulkhead receives 120-Vac power from the 120-Vac input box through the corresponding drop cord and supplies power to the controller circuit breaker.
<i>120-Vac Circuit Breaker</i>	The 120-Vac circuit breaker (CB2) in each control system bulkhead receives power from the 120-Vac power receptacle and supplies power to the controller power supply.
<i>Voltage-adjust Connection</i>	Each control system bulkhead contains a voltage-adjust (VA) connection that attaches to VA cables. The VA connections and cables connect the standby 12-Vdc output module in side B to the voltage-adjust board in side A and provide a secondary power circuit (in addition to the main 12-Vdc output circuit) for the voltage-adjust board.
<i>LAN Connections</i>	Each control system bulkhead contains two 4-pin local area network (LAN) connections (J7 and J8). A cable connects the LAN connection (J8) in the bulkhead in the main PLC to the LAN connection (J8) in the standby PLC; the cable provides the data-exchange interface between the two controllers. Another cable connects the LAN connection (J7) in each of the two control system bulkheads to the corresponding HEU.
<i>Serial-port Connections</i>	Each control system bulkhead contains two 9-pin serial-port connections that you can use to load or change the control system microcode. Serial cables connect one of the serial connections (J6) in each controller to serial-port connections in the support system. The other serial connection (J5) in either bulkhead can connect to the serial cable of a personal computer. During normal system operation, when you are not changing microcode, these two serial-port connections (J5) are not used.
<i>Control Connections</i>	Both control system bulkheads in the mainframe contain four (50-pin) control connections (J1 through J4) that provide the interconnections between the controllers and the control sensors inside the mainframe chassis. Cables connect the control connections in the bulkheads to the mainframe penetrator connections (120 through 123), which are located above each control system bulkhead. Table 12 lists the cable connections from the control system to the penetrator receptacles.

Table 12. Control Cable Connections

Control Connection	Penetrator Receptacle
J1 Main	120 Side A
J2 Main	121 Side A
J3 Main	120 Side B
J4 Main	121 Side B
J1 Standby	122 Side A
J2 Standby	123 Side A
J3 Standby	122 Side B
J4 Standby	123 Side B




Figure 37. Control System Bulkhead Components, Main PLC Assembly

Level Sensors

Ten level sensors (five in side A and five in side B) monitor the level of dielectric coolant within the mainframe. These sensors are located in strategic positions within the mainframe tank so that they can monitor the presence of coolant at specific levels during the mainframe fill and drain processes.

Two level sensors (primary and backup) monitor the presence (tank full condition) of the dielectric coolant in the top area of each side of the mainframe. Two additional level sensors (primary and backup) monitor the presence (power supply full condition) of dielectric-coolant in the lower area of each side of the mainframe. One more level sensor in each mainframe drain monitors the presence (tank empty condition) of dielectric coolant at the mainframe-to-HEU return line during the drain process. Figure 38 illustrates the level sensors and their locations in side A. Figure 38 also illustrates four of the five level sensor locations in side B; the fifth level sensor is located in the side B drain.




Figure 38. Level Sensor Locations

*Voltage
Sense Points*

Voltage sense points allow the control system to monitor the voltage of each power bus and to signal appropriate adjustments to the power supplies for voltage output. Six voltage sense posts on each common memory (CM) bus and four sense posts on each central processor (CP) bus connect to wires that route the voltage levels of each bus to the control system. Figure 39 illustrates the 20 voltage sense point locations in side A of the mainframe. The sense point locations in side B are the same as the sense point locations in side A.




Figure 39. Voltage Sense Points

Current Sensors

The current output of each power supply is measured through the imon + and imon – connections on each power supply, except the clock power supply. The power supplies send this current measurement through the two control system multiplexer (MUX) boards and then to the voltage input modules in the two controllers.

Control System MUX Board

The two control system MUX boards receive the sensor and monitor information and route the information to the appropriate PLC component. Figure 40 illustrates the MUX board location in side A of the mainframe. The other MUX board mounts inside the 8-position power supply door on side B. Refer also to the following subsection, “Monitored Conditions and Limits,” for a detailed description and illustration of the MUX board and its components.




Figure 40. Control System MUX Board Locations

Control System Configuration

Because each CRAY T90 series computer system has different component configurations, the control system configuration differs as well. Basically, the only change in the control system configuration that occurs among different systems is the numbering scheme for the remote monitoring blocks. Each remote monitoring block has a number associated with it; Figure 41 provides the numbering scheme for the CRAY T932 control system.




Figure 41. CRAY T932 Control System Configuration

Monitored Conditions and Limits

The control system monitors and controls numerous conditions. Four PLC components in each of the two controllers provide this status and control information: the TTL input modules, the 12-Vdc output modules, the analog input base converters, and the analog input voltage expanders (two in each controller). In addition to these components in both controllers, the analog output board in the main controller monitors voltage outputs and is used for power supply margining.

Table 13 lists the conditions that the control system monitors. Table 14 through Table 19 provide information about the PLC components.

Table 13. Monitored Conditions

Conditions	Label Description	Location	Description
Dielectric-coolant level	TankFullP TankFullB	Module section	Two level sensors (primary and backup) monitor the dielectric-coolant level at the top of the module section in each side.
	TankEmpty		One level sensor monitors the dielectric-coolant level at the bottom of the module section in each side.
	PS_FullP PS_FullB	Power supply section	Two level sensors (primary and backup) monitor the dielectric-coolant level at the top of the power supply section in each side.
Connector check 1	ConnCheck1	J1 connector	Connector check of the J1 connector to verify correct cabling; that side will not power up if this connector is not cabled correctly.
Connector check 2	ConnCheck2	J2 connector	Connector check of the J2 connector to verify correct cabling; that side will not power up if this connector is not cabled correctly.
Laser check	LaserAlarm1 LaserAlarm2	Optical clock module	One signal comes back from each of the two lasers on the optical clock module to indicate whether the laser is functioning properly.
Power supply flag	D1, D2, and D3	Power supply	All power supply good signals are multiplexed into the D1 – D3 connections.
Power supply enable	Enable27 Enable35 Enable52 EnableClk PS_EN52 PS_EN35 PS_EN27	Power supply	The control system sends a signal to each power supply to enable it. The power supplies are enabled based on the type of voltage the power supply produces.

Table 13. Monitored Conditions (continued)

Conditions	Label Description	Location	Description
Power supply margin enable	MargEn27 MargEn35 MargEn52 MargEn20 MargEnClk	Power supply	The control system sends a signal to each power supply to enable the margining control function.
Voltage measurement	-2.7 V CM Q1 -3.5 V CM Q1 -5.2 V CM Q1 -2.7 V CP Q1 -3.5 V CP Q1 -2.0 V IO Q1 -2.7 V CM Q2 -3.5 V CM Q2 -5.2 V CM Q2 -2.7 V CP Q2 -3.5 V CP Q2 -2.0 V IO Q2	Module power bus	The controller measures the voltage along each module power bus in the two quadrants in that particular side of the mainframe.
HVDC check	HVDC 1 – 6	HVDC line 1 through line 6	The controller measures the voltage of all six HVDC supply lines on that side.
Current measurement	imon 1 – 44 multiplexed to A1, A2, and A3	Power supplies	The control system measures the current of each power supply, except the clock power supply.
Optical clock module select	LaserSelect	Optical clock module	The control system selects which laser will be used.
Clock select	ClockSel0 ClockSel1 ClockSel2	Clock power supply	The control system sets clock speed bits 0, 1, and 2.
Boundary scan continuity line (burn-line) check	Continuity Circuit	Boundary scan module	The control system monitors the boundary scan module continuity line for any error codes. The boundary scan continuity line returns a sum of 1 for an error or a sum of 0 for no errors.

Table 14. TTL Input Module

Label	Data Reference	Label Description	Description	LED Status	
				On	Off
A1	%I105	TankFullP	Mainframe tank is full	Wet	Dry
A2	%I106	Spare	Not used		
A3	%I107	TankFullB	Mainframe tank is full	Wet	Dry
A4	%I108	PS_FullP	Mainframe power supply section is full	Wet	Dry
A5	%I109	PS_FullB	Mainframe power supply section is full	Wet	Dry
A6	%I110	Tank Empty	Mainframe tank is completely empty	Wet	Dry
A7	%I111	ConnCheck1	Check J1	ok	Fault
A8	%I112	Spare2	Not used		
B1	%I113	D1	MUX output		
B2	%I114	D2	MUX output		
B3	%I115	D3	MUX output		
B4	%I116	Remote Control	Check other controller (controlling?)	Controlling	Not controlling
B5	%I117	Remote Run	Check other controller (running?)	Running	Not running
B6	%I118	ConnCheck2	Check J2	ok	Fault
B7	%I119		Not used		
B8	%I120		Not used		
C1	%I121		Not used		
C2	%I122		Not used		
C3	%I123		Not used		
C4	%I124		Not used		
C5	%I125		Not used		
C6	%I126		Not used		
C7	%I127		Not used		
C8	%I128		Not used		
D1	%I129		Not used		
D2	%I130		Not used		
D3	%I131		Not used		
D4	%I132		Not used		
D5	%I133		Not used		
D6	%I134		Not used		
D7	%I135		Not used		
D8	%I136		Not used		

Table 15. 12-Vdc Output Module

Label Reference	Data Reference	Label Description	Function	LED Status	
				On	Off
A1	%Q105	Enable27	-2.7-V-power supplies enabled	Enabled	Disabled
A2	%Q106	Enable35	-3.5-V-power supplies enabled	Enabled	Disabled
A3	%Q107	Enable52	-5.2-V-power supplies enabled	Enabled	Disabled
A4	%Q108	EnableClk	Clock module power supply enabled	Enabled	Disabled
A5	%Q109	LaserSelect	Laser select	Selected	Not selected
A6	%Q110	ClockSel1	Refer to Table 16 for information about the clock speed selection.		
A7	%Q111	ClockSel2			
A8	%Q112	ConnTest1	Test J1	Testing	Not testing
B1	%Q113	S1	MUX select line 1	Enabled	Disabled
B2	%Q114	S2	MUX select line 2	Enabled	Disabled
B3	%Q115	S3	MUX select line 3	Enabled	Disabled
B4	%Q116	S4	MUX select line 4	Enabled	Disabled
B5	%Q117	PS_EN52	Power staging -5.2-V enable	Enabled	Disabled
B6	%Q118	PS_EN35	Power staging -3.5-V enable	Enabled	Disabled
B7	%Q119	PS_EN27	Power staging -2.7-V enable	Enabled	Disabled
B8	%Q120	Spare			
C1	%Q121	InControl	This controller in charge	Controlling	Not controlling
C2	%Q122	Running	This controller running	Running	Not running
C3	%Q123	ConnTest2	Test J2	Testing	Not testing
C4	%Q124	MargEn27	-2.7-V power supplies margin enabled	Enabled	Disabled
C5	%Q125	MargEn35	-3.5-V power supplies margin enabled	Enabled	Disabled
C6	%Q126	MargEn52	-5.2-V power supplies margin enabled	Enabled	Disabled
C7	%Q127	MargEnClk	Clock power supply margin enabled	Enabled	Disabled
C8	%Q128	MargEn20	-2.0-V power supplies margin enabled	Enabled	Disabled
D1	%Q129		Not used		
D2	%Q130		Not used		
D3	%Q131		Not used		
D4	%Q132		Not used		
D5	%Q133		Not used		
D6	%Q134		Not used		
D7	%Q135		Not used		
D8	%Q136		Not used		

Table 16. Clock Select Options

Clock Select Status		Clock Speed
2	1	
Off	Off	Slow
Off	On	Normal
On	Off	Fast
On	On	External

Table 17. Analog Input Base Converter

Channel	Data Reference	Label Description	Function	Values	
				High	Low
1	%AI13	Continuity Circuit Primary	Boundary scan primary circuit faults	None	0.5 V
2	%AI14	Continuity Circuit Backup	Boundary scan backup circuit faults	None	0.5 V
3	%AI15	Analog MUX 1	Scan power supply currents		
4	%AI16	Analog MUX 2	Scan power supply currents		
5	%AI17	Analog MUX 3	Scan power supply currents		
6	%AI18	HVDC 1	Voltage on input line 1 from HVDC	350 V	280 V
7	%AI19	HVDC 2	Voltage on input line 2 from HVDC	350 V	280 V
8	%AI20	HVDC 3	Voltage on input line 3 from HVDC	350 V	280 V

Table 18. Analog Input Voltage Expander, Channel Address

Label Reference	Data Reference	Label Description	Function	Values	
				High	Low
Channel 1	%AI21	27CP1	–2.7 V to CP stack in first quad	+20 %	–20 %
Channel 2	%AI22	35CP1	–3.5 V to CP stack in first quad		
Channel 3	%AI23	20IO1	–2.0 V to IO module in first quad		
Channel 4	%AI24	27CM1	–2.7 V to CM stack in first quad		
Channel 5	%AI25	35CM1	–3.5 V to CM stack in first quad		
Channel 6	%AI26	52CM1	–5.2 V to CM stack in first quad		
Channel 7	%AI27	27CP2	–2.7 V to CP stack in second quad		
Channel 8	%AI28	35CP2	–3.5 V to CP stack in second quad		
Channel 9	%AI29	20IO2	–2.0 V to IO module in second quad		
Channel 10	%AI30	27CM2	–2.7 V to CM stack in second quad		
Channel 11	%AI31	35CM2	–3.5 V to CM stack in second quad		
Channel 12	%AI32	52CM2	–5.2 V to CM stack in second quad		
Channel 13	%AI33	Clock	Voltage from clock box		
Channel 14	%AI34	HVDC4	Voltage on input line 4 from HVDC	350 V	280 V
Channel 15	%AI35	HVDC5	Voltage on input line 5 from HVDC	350 V	280 V
Channel 16	%AI36	HVDC6	Voltage on input line 6 from HVDC	350 V	280 V

Table 19. Analog Input Voltage Expander, Address Label

Label Reference	Function
A1	Margin signal for –2.7-V bus
A2	Margin signal for –3.5-V bus
A3	Margin signal for –5.2-V bus
A4	Margin signal for –2.0-V bus
A5	Margin signal for clock
A6 through A32	Not used
C1	Margin return signal for –2.7-V bus
C2	Margin return signal for –3.5-V bus
C3	Margin return signal for –5.2-V bus
C4	Margin return signal for –2.0-V bus
C5	Margin return signal for clock
C6 through C32	Not used

Control System MUX Board

The control system requires numerous connections in order to route the monitored information to the appropriate control system components. The two control system MUX boards provide the main interface connections between the PLCs and the mainframe components.

Each MUX board consists of a 6-layer printed circuit board and electronic interconnection components such as connectors, integrated circuits, diodes, and resistors. Refer to Figure 42 for an illustration of the MUX board and its components. Refer to Figure 43 for an illustration of the connector pin layouts. Table 20 provides information about the MUX board components to help explain the theory of operation of the control system; each MUX board is a field replaceable unit that does not require field repair.




Figure 42. Control System MUX Board




Figure 43. Connector Pin Layout

Table 20. MUX Board Components

Device	Device Type	Function
PWR1	7-pin DC/DC converter	Converts 12 Vdc to +15 Vdc, -15 Vdc, and +5 Vdc
J1 – J2	50-pin connectors	Connections through bulkhead to main controller
J3 – J4	50-pin connectors	Connections through bulkhead to standby controller
J5	8-pin connector	Connection to IO module in the first quadrant
J6	8-pin connector	Connection to IO module in the second quadrant
J7	6-pin connector	Connection to BS module
J8	8-pin connector	Reserved for future enhancement
J14	6-pin connector	Connection to Tank Empty level sensor
J15	6-pin connector	Connection to Tank Full P level sensor
J16	6-pin connector	Connection to Tank Full B level sensor
J17	8-pin connector	Connection to Power Supply Full level sensor
P1	26-pin connector	Connection to 8-position power supply rack
P6	14-pin connector	Current monitor connection to 8-position rack
P13	24-pin connector	Connection to 8-position power supply rack
P2	48-pin connector	Connection to 20-position power supply rack
P3	28-pin connector	Connection to 20-position power supply rack
P7	42-pin connector	Current monitor connection to 20-position rack
P4	20-pin connector	Connection to 16-position power supply rack
P5	40-pin connector	Connection to 16-position power supply rack
P8	34-pin connector	Current monitor connection to 16-position rack
U1 – U7, U16	16-pin ICs	Digital MUX connections
U8 – U10, U23	28-pin multiplexers	Analog MUX connections
U11 – 15, U17 – U19	6-pin low-input couplers	Opto-coupler connections
U20 – 22, U30 – 32	14-pin ICs	OP amp (quad)
C1 – C21	Capacitors	Circuit current storage
C42 – C53	Capacitors	Circuit current storage
CP1 – CP7	Capacitors	Current filters
D1 – D16	Diodes	Current rectifiers
R1 – R37	Resistors	Line resistance
RP1 – RP10	Resistor packs	Circuit resistance
RP17 – RP30	Resistor packs	Circuit resistance

For more specific information about the MUX board, the bulkhead and PLC interconnections, and the control system operation, refer to the MUX schematic and the *Power, Cooling, and Control System Troubleshooting Guide*, Cray Research publication number HTM-179-0.

Control System Processes

The control system regulates certain power and cooling processes for the mainframe and peripheral devices. This subsection provides only an overview of the control system processes and a brief description of the warning and control system (WACS) commands used to monitor and control these processes. Additional information about control system processes and WACS commands is available in a separate control system troubleshooting document.

Power-up Process

The power-up process for each side of the CRAY T932 mainframe is a complex process because of the many system conditions that must be checked prior to the power-up. The power-up process for each side includes the following tasks:

- Start command sent
- Mainframe filled
- Dielectric coolant circulated
- HVDC enabled
- Power buses checked for shorts
- Power supplies enabled and voltage applied to power buses
- Continuity circuit checked

Refer to Figure 44 for a flowchart of the power-up process.




Figure 44. Power-up Sequence of Events

Power-down Process

The power-down process also involves a sequence of events that protects the computer system from internal damage and prevents loss of data. The power-down process for each side of the mainframe includes the following tasks:

- Stop command sent or fault condition detected by controller
- LVDC module buses disabled
- 330-Vdc power disabled to power input terminals (HVDC disabled)
- Pump stopped

Refer to Figure 45 for a flowchart of the power-down process.




Figure 45. Power-down Sequence of Events

Mainframe Drain Process

The mainframe drain process can operate according to two unique subprocesses; depending on the task, either side of the mainframe can be completely drained or partially drained. If a side is being powered down because of a customer request or a computer system interrupt, that side does not have to be drained. However, if either side of the mainframe requires maintenance, the type of maintenance required determines how that side is drained. If a module needs replacement, the side may be partially drained. If a power supply needs replacement, that side of the mainframe must be completely drained. The mainframe drain process includes the following tasks:

- Drain command sent
- HVDC disabled
- LVDC disabled
- HEU valves set
- Dielectric coolant suctioned into reservoir by HEU pump until the desired tank coolant level is reached

Figure 46 provides a flowchart of the drain process for either side of the mainframe.




Figure 46. Drain Sequence of Events

Mainframe Fill Process

The mainframe fill process occurs in relatively the same manner for both sides of the mainframe. The pump in the corresponding HEU-T90 circulates dielectric coolant from the HEU reservoir into the mainframe tank until the level sensors indicate that the tank is full on that side of the mainframe. Even though this process seems simple, it includes the following five basic steps:

- Fill command sent
- HEU valves set
- Pump enabled
- Tank filled with coolant until the tank full primary or backup sensor is wet
- Pump stopped

Figure 47 provides a flowchart of this fill process.




Figure 47. Fill Sequence of Events

WACS Commands and Sequence of Events

The computer control system uses commands sent by the WACS program to control the sequences of events in the power and cooling processes. All WACS commands have redundant tasks embedded within them that the control system performs as part of the command selection. The operator can monitor, activate, or change the task sequences of the control processes by selecting a combination of buttons or switches from the WACS menu. The following list describes some of the WACS menu selections:

- Start
- Stop
- Fill Tank
- Circulate
- Empty Modules
- Empty Tank

Figure 48 on page 93 illustrates the WACS switches menu for the CRAY T932 mainframe.

WACS Fault Limits

The computer control system monitors the bus voltages, the coolant flow rate, the tank pressure, and other conditions in the CRAY T932 system. The WACS program receives information about the monitored conditions in the system and displays the information on the workstation WACS screen. The computer system operates normally within predefined (normal) limits. When a monitored condition exceeds the normal limit, the WACS program records a fault condition and initiates action in the form of either a warning message, an immediate system shut-down, or a time-delayed system shut-down. Table 21 on page 94 provides the fault limits for the CRAY T932 system during normal operation.

T32_Main: Serial 7201

Read Switches Write Switches Load Defaults Save Defaults

Clock: Normal Laser:

***** Side A ***** Side B *****

Start Empty Modules Fill Tank Empty Modules

Stop Empty Tank Circulate Empty Tank

HEU Bypass:

Quad 1 CP -2.7v Margin:	Low	Normal	High	User
Quad 1 CP -3.5v Margin:	Low	Normal	High	User
Quad 1 IO -2.0v Margin:	Low	Normal	High	User
Quad 1 CM -2.7v Margin:	Low	Normal	High	User
Quad 1 CM -3.5v Margin:	Low	Normal	High	User
Quad 1 CM -5.2v Margin:	Low	Normal	High	User
Quad 2 CP -2.7v Margin:	Low	Normal	High	User
Quad 2 CP -3.5v Margin:	Low	Normal	High	User
Quad 2 IO -2.0v Margin:	Low	Normal	High	User
Quad 2 CM -2.7v Margin:	Low	Normal	High	User
Quad 2 CM -3.5v Margin:	Low	Normal	High	User
Quad 2 CM -5.2v Margin:	Low	Normal	High	User

All Voltage Margins

Clock -5.2v Margin:

Figure 48. WACS Switches Menu

NOTE: Some of the WACS fault limits change during specific system operations. The values listed in Table 21 represent the fault limits of the CRAY T932 computer system during normal operating conditions.

Table 21. Fault Limits, CRAY T932 System, Side A or Side B

Sense Point	Low Limit	High Limit	Action/Notes
-2.7-Vdc Bus voltage	-2.44 Vdc	-3.66 Vdc	Shut-down
-3.5-Vdc Bus voltage	-3.02 Vdc	-4.54 Vdc	Shut-down
-5.2-Vdc Bus voltage	-4.30 Vdc	-6.44 Vdc	Shut-down
-2.0-Vdc Bus voltage	-1.60 Vdc	-2.40 Vdc	Shut-down
Clock bus voltage	-4.16 Vdc	-6.24 Vdc	Shut-down
Fluorinert flow rate	174 gpm	188 gpm	Shut-down/60-second delay
Fluorinert supply temperature	22 °C	14 °C	Shut-down/60-second delay
Fluorinert return temperature	No limit	No limit	No message
Tank pressure (low)	20 psi	–	Shut-down/1-second delay
Tank pressure (high)	–	$P = (FR \div 11.25) + 25$ †	Shut-down/25 @flow = 0 Shut-down/41 @flow = 180 ‡
-2.7-Vdc Bus amps	No limit	200-A change	Shut-down/100-A message
-3.5-Vdc Bus amps	No limit	200-A change	Shut-down/100-A message
-5.2-Vdc Bus amps	No limit	600-A change	Shut-down/350-A message
HVDC voltage	300 Vdc	350 Vdc	Message only
HEU reservoir level	5%	No limit	Message only
HEU water flow rate	No limit	No limit	No message
HEU water inlet temperature	No limit	No limit	No message
HEU water outlet temperature	No limit	No limit	No message
HEU pump discharge pressure	No limit	No limit	No message
HEU pump suction pressure	No limit	No limit	No message

† Use this formula to calculate the tank pressure; P represents the tank pressure and FR represents the Fluorinert flow rate.
‡ The minimum high-pressure fault value is 25 psi (FR = 0), and the maximum high-pressure fault value is 41 psi (FR ≥ 180 gpm).

Reader Comment Form

**Title: Power, Cooling, and Control System
(CRAY T932™ System)**

Number: HTM-095-B

Your feedback on this publication will help us provide better documentation in the future. Please take a moment to answer the few questions below.

For what purpose did you primarily use this document?

Troubleshooting Tutorial or introduction
 Reference information Classroom use
 Other - please explain _____

Using a scale from 1 (poor) to 10 (excellent), please rate this document on the following criteria and explain your ratings:

Accuracy _____
 Organization _____
 Readability _____
 Physical qualities (binding, printing, page layout) _____
 Amount of diagrams and photos _____
 Quality of diagrams and photos _____

Completeness (Check one and provide comments).

Too much information Too little information Correct amount

You may write additional comments in the space below. Mail your comments to the address below, fax them to us at +1 715 726 4353, or e-mail them to us at *spt@cray.com*. When possible, please give specific page and paragraph references. We will respond to your comments in writing within 48 hours.

NAME _____
JOB TITLE _____
E-MAIL ADDRESS _____
SITE/LOCATION _____
TELEPHONE _____
DATE _____

[or attach your business card]



Service Publications and Training
890 Industrial Boulevard
P.O. Box 4000
Chippewa Falls, WI 54729-0078
USA